



MARITIME GEOTHERMAL LTD.



Installation and Service Manual

R-Series
Slim Design
Two-Stage R410a
Model Sizes 25-80

Liquid to Air Geothermal Heat Pumps



Maritime Geothermal Ltd.
P.O. Box 2555
Petitcodiac, N.B. E4Z 6H4
Ph. (506) 756-8135

Email: info@nordicghp.com
Web: www.nordicghp.com
Document Number: **001200MAN-05**



SAFETY PRECAUTIONS



WARNING: Ensure all access panels are in place and properly secured before applying power to the unit. Failure to do so may cause risk of electrical shock.


WARNING: Before performing service or maintenance on the heat pump system, ensure all power sources are DISCONNECTED. Electrical shock can cause serious personal injury or death.

WARNING: Heat pump systems contain refrigerant under high pressure and as such can be hazardous to work on. Only qualified service personnel should install, repair, or service the heat pump.

CAUTION: Safety glasses and work gloves should be worn at all times whenever a heat pump is serviced. A fire extinguisher and proper ventilation should be present whenever brazing is performed.

CAUTION: Venting refrigerant to atmosphere is illegal. A proper refrigerant recovery system must be employed whenever repairs require removal of refrigerant from the heat pump.

MODEL NOMENCLATURE



APPLICATION TABLE											
SIZE	FUNCTION	REFRIGERANT	VOLTAGE	COMPRESSOR STAGES*	OUTDOOR COIL	FAN/CASE	REVISIONS				
25	HACW	P	1	T	C Z	SDELF SDERF	09				
			2	T			09				
			6	T			09				
			7	T			09				
45	HACW	P	1	T	C Z	SDELF SDERF	09				
			2	T			09				
			6	S			09				
			7	T			09				
55	HACW	P	1	T	C Z	SDELF SDERF	09				
			2	T			09				
			6	S			09				
			7	T			09				
65	HACW	P	1	T	C Z	SDELF SDERF	09				
			2	T			09				
			6	S			09				
			7	T			09				
75	HACW	P	1	T	C Z	SDELF SDERF	09				
			2	T			09				
			6	S			09				
			7	T			09				
80	HACW	P	1	S	C Z	SDELF SDERF	09				
			2	S			09				
			7	S			09				
This manual applies only to the models and revisions listed in this table * T = Two Stage, S = Single Stage											

Maritime Geothermal Ltd. has a continuous improvement policy and reserves the right to modify specification data at any time without prior notice .

Table of Contents

TABLES, DIAGRAMS & DRAWINGS:	PAGE 5
INSTALLATION INFORMATION:	PAGE 6
Unit description:	Page 6
Unpacking the unit:	Page 6
Optimum Placement:	Page 6
Electrical Connections:	Page 6
Control Transformer :	Page 6
Circulator Pump Module Wiring (Ground Loop Only):	Page 6
Thermostat Requirements:	Page 7
Fan Motor:	Page 7
Fan Return Orientation:	Page 7
Fan Outlet Orientation :	Page 7
Safety Controls:	Page 7
Domestic Hot Water Connections (HACW only):	Page 8
SIZING AND DUCTWORK:	PAGE 11
Heat Pump Sizing:	Page 11
Duct Systems - General:	Page 11
Duct Systems - Grill Layout:	Page 11
Thermostat Location:	Page 12
Plenum Heater (Optional):	Page 12
Condensate Drain:	Page 12
Duct Sizing Guide:	Page 14
GROUND WATER SYSTEM INFORMATION:	PAGE 15
General Requirements:	Page 15
Plumbing the Heat Pump:	Page 15
Pipe Insulation:	Page 15
Water Discharge Methods:	Page 15
GROUND LOOP SYSTEM INFORMATION:	PAGE 18
Circulator Pump Module:	Page 18
Flushing & Purging the Ground Loop:	Page 18
Adding Antifreeze Solution:	Page 19
Initial Pressurization:	Page 19
Pipe Insulation:	Page 19
STARTUP PROCEDURE:	Page 21
Pre-start Inspection:	Page 21
Unit Startup:	Page 22
Startup Record:	Page 23
GENERAL MAINTENANCE:	PAGE 24
TROUBLESHOOTING GUIDE:	PAGE 25
Repair Procedures:	Page 34
MODEL SPECIFIC INFORMATION:	PAGE 35
Refrigerant Charge Chart:	Page 35
Shipping Information:	Page 35
Standard Capacity Ratings:	Page 35
Capacity Ratings:	Page 37
Electrical Tables:	Page 43
Electrical Diagrams:	Page 45
Refrigeration Circuit Diagrams:	Page 49
Case Details:	Page 51
APPENDIX A: Control Board Specifications:	PAGE 57
APPENDIX B: ECM Fan Airflow Tables:	PAGE 58
WARRANTY INFORMATION:	PAGE 60

Tables, Diagrams and Drawings

TABLES

Table 1 - Power Supply Connections (Heat Pump):	Page 6
Table 2 - Power Supply Connections (Optional Plenum Heater):	Page 6
Table 3 - Control Signal Description:	Page 7
Table 4 - Airflow Selections:	Page 7
Table 5 - Control Board Fault Codes:	Page 8
Table 6 - Heat Pump Size vs. Heated Area for Ground Loop Systems:	Page 11
Table 7 - Heat Pump Size vs. Heated Area for Ground Water Systems:	Page 11
Table 8 - Heat Pump Size vs. Hot Air Grills:	Page 12
Table 9 - Plenum Heater Sizing:	Page 12
Table 10 - Duct Sizing Guide:	Page 14
Table 11 - Required Flow and Air Tank Sizing:	Page 15
Table 12 - Antifreeze Percentages by Volume:	Page 19
Table 13 - Volume of Fluid per 100ft. Of Pipe:	Page 19
Table 14 - Refrigerant Charge Chart:	Page 35
Table 15 - Shipping Information:	Page 35
Table 16 - Standard Capacity Ratings - Ground Loop Heating 60Hz:	Page 35
Table 17 - Standard Capacity Ratings - Ground Water Heating 60Hz:	Page 35
Table 18 - Standard Capacity Ratings - Ground Loop Cooling 60Hz:	Page 36
Table 19 - Standard Capacity Ratings - Ground Water Cooling 60Hz:	Page 36
Table 20 - Heat Pump Electrical Information (208/230-1-60):	Page 43
Table 21 - Heat Pump Electrical Information (208-3-60):	Page 43
Table 22 - Heat Pump Electrical Information (460-3-60):	Page 43
Table 23 - Heat Pump Electrical Information (220-1-50):	Page 43
Table 24 - Heat Pump Electrical Information (380-3-50):	Page 44
Table 25 - Plenum Heater Electrical Information (208/230-1-60):	Page 44

DIAGRAMS

Diagram A - Typical P/T (Pete's) Plug & Thermometer Stem:	Page 18
Diagram B - Typical Purge Cart:	Page 18
Case Details - Left Return - Size 25 to 75:	Page 51
Case Details - Right Return - Size 25 to 75:	Page 53
Case Details - Left Return - Size 80:	Page 55
Case Details - Right Return - Size 80:	Page 56

DRAWINGS

001827CDG - Typical Thermostat Connections:	Page 9
000970PDG - Single Unit Connection to DHW Pre-Heat Tank (Brass FPT):	Page 10
001201CDG - Typical Duct and Condensate Connections (Modular Case):	Page 13
000907CDG - Typical Ground Water Installation for Size 25-75 Heat Pumps (Brass FPT):	Page 16
000619INF - Ground Water Disposal Methods:	Page 17
000906CDG - Geo-Flo Circulator Pump Module Installation (Brass FPT):	Page 20
001754SCH-01 - R-25-75-HAC*-P-1*-**DE** Schematic Diagram:	Page 45
001755ELB-01 - R-25-75-HAC*-P-1*-**DE** Electrical Box Diagram:	Page 46
001135SCH-03 - R**-HAC*-P-1*-**DE** Schematic Diagram:	Page 47
001136ELB-03 - R**-HAC*-P-1*-**DE** Electrical Box Diagram:	Page 48
001207RCD - R(H)-Series Refrigeration Circuit Diagram—Heating Mode:	Page 49
001208RCD - R(H)-Series Refrigeration Circuit Diagram—Cooling Mode:	Page 50

Installation Information

UNIT DESCRIPTION

The R-Series unit is a high efficiency two-stage geothermal heat pump. Two-stage units offer longer runtimes and fewer cycles resulting in higher efficiency and a higher comfort level. The heat pump contains environmentally friendly R410a refrigerant.

An electrically commutated (ECM) fan with several speed options is standard. The motor has a soft start function for improved efficiency and reduced wear.

The unit has several key features that are described in the specifications document for the particular heat pump. Please request a copy if desired or visit www.nordicghp.com

UNPACKING THE UNIT

When the heat pump reaches its destination it should be unpacked to determine if any damage has occurred during shipment. Any visible damage should be noted on the carrier's freight bill and a suitable claim filed at once.

The heat pump is well constructed and every effort has been made to ensure that it will arrive intact, however it is in the customer's best interest to examine the unit thoroughly when it arrives.

OPTIMUM PLACEMENT

For liquid to air units, to achieve the greatest efficiency, the heat pump should be centrally located in the home with respect to the conditioned space. This design provides the utmost in economy and comfort and usually can be accomplished in harmony with the design of the home. A heating system cannot be expected to produce an even warmth throughout the household when it is located at one end of the structure and the warm air is transmitted with uninsulated metal ductwork.

If possible the access panels should remain clear of obstruction for a distance of **two feet** to facilitate servicing and general maintenance.

Raising the heat pump off the floor a few inches is generally a good practice since this will prevent rusting of the bottom panel of the unit. We recommend that the heat pump be placed on a piece of 2" thick styrofoam. The styrofoam will smooth out any irregularities in the cement floor and deaden any compressor noise emitted from the bottom of the cabinet.

The heat pumps come equipped with an air-filter rack which can be installed with the removable end (where the filter is inserted) on either side to facilitate changing the filter.

ELECTRICAL CONNECTIONS

The heat pump has a concentric 1.093" / 0.875" knockout for power supply connection to the electrical box, as well as one for connection to the circulator pump module for ground loop applications. There are two 1/2" openings with plastic grommets (grommet hole is 3/8") in the upper section of the electrical box, one for the thermostat connections, and one for the optional plenum heater connections.

A schematic diagram (SCH) and electrical box layout diagram (ELB) can be found inside the electrical box cover of the unit as well as in the **Model Specific** section of this manual.

The Electrical Tables in the **Model Specific** section and the ELB diagram contain information about the size of wire for the connections, as well as the recommended breaker size for both the heat pump and optional plenum heater. Connections are as per **TABLE 1** and **TABLE 2**.

NOTE: There are two separate power supplies, one for the heat pump and a second one for the plenum heater if installed, each must have its supply wires and breaker.

NOTE: A properly qualified electrician should be retained to make the connections to the heat pump and associated controls. The connections to the heat pump **MUST CONFORM TO LOCAL CODES**.

**TABLE 1 - Power Supply Connections
(Heat Pump)**

Line	Description	Voltages
L1	Line 1	All
L2	Line 2	All
L3	Line 3	208-3-60, 460-3-60, 380-3-50
N**	Neutral	208/230-1-60, 208-3-60, 380-3-50

** Only required if connecting 115VAC circulators to the heat pump for 208/230-1-60 and 208-3-60 models, the heat pump itself does not require a neutral. Required for 380-3-50 models.

**TABLE 2 - Power Supply Connections
(Optional Plenum heater)**

Line	Description	Voltages
L1	Line 1	208/230-1-60, 208-3-60
L2	Line 2	208/230-1-60, 208-3-60

Contact factory for three phase plenum heater requirements.

CONTROL TRANSFORMER

The low voltage controls are powered by a 75VA class II transformer. The transformer has a resettable breaker on the secondary side for circuit protection. Should the breaker trip, locate and correct the problem and then reset the breaker by pressing in on it.

IMPORTANT NOTE: For 208/230VAC-1-60 units, if connecting to 208VAC power supply move the red wire connected to the 240 terminal of the transformer to the 208 terminal of the transformer.

CIRCULATOR PUMP MODULE WIRING (GROUND LOOP ONLY)

The heat pump has provisions for connecting the circulator pump module so that the pumps will be turned on whenever the compressor operates. Connect the circulator pump module to the appropriate two terminals of the terminal strip marked **OUTDOOR CIRCULATORS** in the heat pump, as per the voltage of the circulator pump module. Ensure that the total current draw does not exceed the value indicated on the label in the heat pump electrical box. Refer to the electrical box drawing on the electrical box cover for more information.

THERMOSTAT REQUIREMENTS

The R-Series model requires a three-stage heating and two stage cooling heat pump configurable thermostat for two-stage models. The stages are S1 = Stage 1 compressor, S2 = Stage 2 compressor and S3 = electric auxiliary (heating only). One can be purchased with the unit, or other heat pump thermostats with the same number of stages can be used. The electrical box diagram on the electrical box cover provides a description of the signal connections as in **TABLE 3**. Refer to **DRAWING 001827CDG** for a diagram of the connections between the thermostat and the heat pump.

NOTE: Some models are not available in two-stage at the present time, models numbers with a T in the Compressor Stages designator are two-stage, models with an S are single stage (verify the model number against pages 2 and 3 of this manual, or refer to the **Electrical Tables** near the end of this manual to determine if the model is two stage or one stage). The Y2 signal is not used for these units, and they only require a 2 stage heat 1 stage cool thermostat. The stages are S1 = Compressor and S2 = electric auxiliary (heating only). If the selected thermostat has more stages than this, configure it for 2 and 1.

TABLE 3 - Control Signal Description

Signal	Description
C	24VAC Common (Ground)
G	Fan low speed (for air circulation)
Y ₁	Heat Pump Stage 1
R _H	24VAC Hot
L	Fault (24VAC when fault condition)
W ₂	Heat Pump Stage 3 (auxiliary heat) / Emergency Heat
O	Cooling Mode (reversing valve)
Y ₂	Heat Pump Stage 2 (Not used for single stage units)
AR ₁	Airflow Reduction*
AR ₂	Airflow Reduction*
C(I)	Plenum Heater dry contact (Connect to C or I in plenum heater)
1	Plenum Heater dry contact. (Connect to 1 and 2 in plenum heater)

* Connect AR₁ to AR₂ with a dry contact to reduce the airflow by 15%. Refer to the **Fan Motor** sub-section for more information.

FAN MOTOR

The unit is equipped with a direct drive ECM fan motor for maximum efficiency. The motor features a soft start which further improves efficiency by eliminating inrush current and provides a smooth, quiet ramp up to speed. The motor will maintain the programmed air flow up to the maximum external static value. Refer to the **APPENDIX B: ECM Fan Airflow Tables**.

The air flow can be set to four different levels by changing the position on the Air Flow board located in the electrical box. The four levels are indicated in **TABLE 4**. The actual air flow values can be found in **APPENDIX B**.

Units are shipped with the **MED** position selected for nominal air flow. The air flow can be further reduced by 15% by making a dry contact across AR₁ and AR₂ on the terminal strip. This can be used for applications that have multiple zones, or

retrofits with undersized ductwork, to help reduce air flow noise in the ductwork. It is recommended that airflow reduction only be used with the High or Max air flow setting. Care should be taken to ensure that the unit does not trip a safety control in heating or cooling mode if the 15% reduction is used in conjunction with the MED or LOW air flow setting.

TABLE 4 - Airflow Selections

Position	Airflow
LOW	-6%
MED	Nominal
HIGH	+6%
MAX	+12%

FAN RETURN ORIENTATION

The R-Series heat pump can be ordered as a left or right hand return from the factory. This must be specified at time of order as the physical construction of the two configurations is different. Refer to the **CASE DETAILS** section of this manual or the specification documents for physical dimensions of the units.

FAN OUTLET ORIENTATION

The R-Series heat pumps have a field configurable fan. It's default location from the factory is in the top of the unit, providing a "ninety" in the airflow. It can easily be placed in the side of the unit for straight through airflow.

To switch the location of the fan outlet follow these simple steps:

1. Turn the power of to the unit.
2. Remove the screw that holds the side access panel in place and remove the access panel by pulling up on the handle and then outward from the bottom.
3. Disconnect the two wire harnesses and ground wire from the fan motor.
4. Repeat step 2 for the access panel with the fan mounted in it. Set the assembly on the floor.
5. Disconnect the plenum heater extension from the fan housing and from the access panel.
6. Mount the fan housing directly to the access panel.
7. Install the fan/panel in the new location and secure with the screw.
8. Reconnect both harnesses and ground wire.
9. Install the remaining access panel and secure with the remaining screw.

SAFETY CONTROLS

The heat pump has two built in safety controls which are designed to protect the unit from situations which could damage it should the operation of the refrigeration circuit fall outside the allowable operating range.

A. Low Pressure Control

The low pressure control monitors the compressor suction pressure and will shut the compressor down if the refrigerant evaporating pressure becomes too low, risking the danger of freezing conditions in the evaporator.

There are (3) main reasons why this control would activate in response to the operating conditions of the unit while operating in heating mode:

1. Low or no Outdoor loop flow.
2. Low Outdoor loop entering liquid temperature.
3. Dirty or fouled Outdoor loop heat exchanger.

B. High Pressure Control

The high pressure safety control monitors the compressor discharge pressure and will shut the compressor down if the condensing pressure becomes too high.

There are (3) main reasons why this control would activate in response to the operating conditions of the unit while operating in heating mode:

1. Low or no airflow.
2. High return air temperature.
3. Dirty air coil due to poor filter maintenance.

The unit contains a control board that monitors the safety controls and operates the compressor accordingly. Refer to **APPENDIX A** for control board specifications. The low pressure control is connected to LP1 and LP2. The high pressure control is connected to HP1 and HP2.

The control board also has provisions for a flow switch. The flow switch is unused from the factory and a jumper wire is placed across the FLOW SWITCH terminals. If a flow switch is desired, the jumper can be removed and the two leads from the flow switch can be connected to the FLOW SWITCH terminals on the safety board. The flow switch is ignored for 5 seconds on compressor startup to allow time for flow to be established. The high and low pressure controls are monitored at all times. The compressor will not be able to start if either of them has a fault.

The control board has an on-board LED and a FAULT pin with a 24VAC output, which is routed to the L terminal of the thermostat terminal strip. An external indicator or relay can be connected across L and C on the terminal strip if external signaling is desired. Should a fault condition occur, the LED will flash the code of the fault condition while the safety control in question is open. The codes are shown in **TABLE 5**. The control board will lock out the compressor for five minutes when a fault occurs. The control board will then restart the compressor if the fault has been cleared. Should a second fault condition occur within a 60 minute period the control board will go into permanent lockout mode and energize the FAULT pin. The LED will flash the fault code until the control board is reset by powering down the unit.

TABLE 5 - Control Board Fault Codes

Fault	LED Flashes
High Pressure	1
Low Pressure	2
Flow	3



WARNING: If the control board enters permanent lockout mode there is a serious problem with the system and it must be rectified if the unit is to maintain good service.



WARNING: REPEATED RESETS OF A LOW PRESSURE LOCKOUT COULD CAUSE THE HEAT EXCHANGER TO FREEZE AND RUPTURE, DESTROYING THE HEAT PUMP AND VOIDING THE WARRANTY.

DOMESTIC HOT WATER CONNECTIONS (HACW only)

The port connections for the DHW circuit are 1/2" brass FPT fittings. They are marked as DHW IN and DHW OUT

A typical piping diagram for a pre-heat tank configuration can be found in **DRAWING 000970PDG** at the end of this section. Be sure to note the position of the check valve and the direction of water flow. Other configurations are possible, and there may be multiple units tied together in larger buildings.



WARNING: USE ONLY COPPER LINES TO CONNECT THE DESUPERHEATER. TEMPERATURES COULD REACH 200F SHOULD THE DHW CUTOFF SWITCH FAIL, POTENTIALLY RUPTURING PEX PIPING.

Ensure the tank is filled with water and under pressure before activating the heat pump. Slightly loosen the boiler drain on the DHW Out pipe to allow air to escape from the system before the unit is started. This step will make certain that the domestic hot water circulator in the unit is flooded with water when it is started.



CAUTION: the domestic hot water pump is water lubricated; damage will occur to the pump if it is run dry for even a short period of time.

Connect the brown wire with the blue insulated terminal to L1 of the compressor contactor. **Ensure the power is off when connecting the wire.**

The DHW loop may have to be purged of air several times before good circulation is obtained. A temperature difference between the DHW In and DHW Out can be felt by hand when the circulator pump is operating properly.


For the pre-heat tank setup, the final tank should be set to **140°F(60°C)**, unless local code requires a higher setting. The pre-heat tank does not require electric elements. This setup takes full advantage of the desuperheater as it is the sole heat provider to the pre-heat tank. The desuperheater remains active during the compressor runtime until the pre-heat tank has been completely heated by the desuperheater alone. This setup is more energy efficient than a single tank setup.




CAUTION: If two (2) shut-off valves are located on the domestic hot water lines as shown in the diagram, a pressure relief valve must be installed to prevent possible damage to the domestic hot water circulator pump should both valves be closed.

Typical Thermostat Connections

Two-Stage Models (Compressor Stages = T)




Single-Stage Models (Compressor Stages = S)




					Drawn By Chris Geddes	Date 18 MAR 2014	MARITIME GEOTHERMAL LTD. 170 Plantation Rd. Petitcodiac, NB E4Z 6H4
					Checked By Chris Geddes	Date 18 MAR 2014	
					Approved By Chris Geddes (ENG)	Date 18 MAR 2014	
					Approved By Chris Geddes (MFG)	Date	
01	Initial Release	C. GEDDES	C. GEDDES	18 MAR 2014	Approved By	Date	Drawing Name Typical Thermostat Connections
REV	ECO #	IMPL BY	APVD BY	DATE			Size A
							Drawing Number 001827SCH
							Drawing Rev 01
							SHEET 1 of 1

Single Unit Connection to Domestic Hot Water Pre-Heat Tank (Brass FPT)

Top Port Configuration



Side Port Configuration



					Drawn By Chris Geddes	Date 10 MAR 09	<div>MARITIME GEOTHERMAL LTD.</div>			170 Plantation Rd. Pettitcodiac, NB E4Z 6H4		
					Checked By Chris Geddes	Date 10 MAR 09						
					Approved By Chris Geddes	(ENG) Date 10 MAR 09	Drawing Name Single Unit Connection to DHW Pre-Heat Tank (Brass FPT)					
					Approved By (MFG)	Date						
01	Initial Release	C. GEDDES	C. GEDDES	10 MAR 09	Approved By	Date	Size A	Drawing Number 000970PDG	REV 01	SHEET 1 of 1		
REV	ECO #	IMPL BY	APVD BY	DATE								

Sizing and Ductwork

HEAT PUMP SIZING

TABLE 6 depicts a rough guideline as to the size of home each heat pump size can handle for **ground loop** installations.

TABLE 6 - Heat Pump Size vs. Heated Area for a Ground Loop System		
Model	Sq.ft.	Sq.m.
25	800	75
45	1,400	130
55	2,000	185
65	2,600	240
75	3,100	290
80	3,500	325

TABLE 7 depicts a rough guideline as to the size of home each heat pump size can handle for **ground water** installations.

TABLE 7 - Heat Pump Size vs. Heated Area for a Ground Water System		
Model	Sq.ft.	Sq.m.
25	1,000	95
45	1,800	165
55	2,500	230
65	3,200	295
75	3,800	355
80	4,200	390

THE TABLES ABOVE ARE FOR INFORMATION ONLY, THEY SHOULD NOT BE USED TO SELECT A UNIT SIZE. They simply show on average what size unit is required for a typical two-level home (main level and below grade basement) with R-20 walls, R-40 ceiling and average size and number of windows. The Heated Area is the area of the main level. The tables account for a basement the same size as the heated area.

MARITIME GEOTHERMAL LTD. HIGHLY RECOMMENDS THAT A PROPER HEAT LOSS/GAIN ANALYSIS BE PERFORMED BY A PROFESSIONAL INSTALLER WITH CSA APPROVED SOFTWARE BEFORE SELECTING THE SIZE OF UNIT REQUIRED FOR THE APPLICATION. For heating dominant areas, we recommend sizing the unit to 100% of the heating design load for maximum long term efficiency with minimal supplementary heat. The unit should be installed as per CSA 448.2-02. For ground loop applications, the ground exchanger should be designed using suitable software with a multi-year analysis.

There are many factors to consider when sizing the heat pump. Some of these factors include the number of levels, the size of the windows, the orientation of the home, attached garage, bonus rooms, walk-in basement, coldest outdoor temperature, etc. The heat loss program will take all of these factors into consideration in its calculations. An undersized installation will not be as efficient as it will require excessive relatively expensive supplemental heat to maintain a comfortable temperature in the home, and the cost savings of having a geothermal

heat pump are greatly reduced.

Once the total heat loss has been calculated, the unit can be sized using the performance tables (from the specifications document) in conjunction with the minimum expected entering liquid temperature of the ground loop (well water temperature for ground water system). The heat pump output must be able to match the total heat loss at the selected entering water temperature in order to provide a comfortable environment with minimal auxiliary heat.

DUCT SYSTEMS - GENERAL

Ductwork layout for a heat pump will differ from traditional hot air furnace design in the number of leads and size of main trunks required. Air temperature leaving the heat pump is normally **95° -105°F (35-40°C)**, much cooler than that of a conventional warm air furnace. To compensate for this, larger volumes of lower temperature air must be moved and consequently duct sizing must be able to accommodate the greater air flow without creating a high static pressure or high velocity at the floor diffusers.

A duct system capable of supplying the required air flow is of utmost importance. Maritime Geothermal Ltd. recommends that the static pressure be kept below 0.2 inches of water total. In some instances the number of floor diffusers will actually double when compared to the number that would be used for a hot air oil-fired furnace. Refer to **TABLE 10** at the end of this section.

1. Generally allow **100 cfm** for each floor grill.
2. All leads to the grills should be 6" in diameter (28sq.in. each).
3. The main hot air trunks should be at least 75% of the square surface area of leads being fed at any given point.
4. Return air grills should have a minimum of the same total square surface area as the total of the supply grills.
5. The square surface area of the return trunks should equal the square surface area of the grills being handled at any given point along the trunk.

It is **VERY IMPORTANT** that all turns in both the supply trunks and the return trunks be made with **TURNING RADII**. Air act like a fluid and, just like water, pressure drop is increased when air is forced to change direction rapidly around a sharp or irregular corner.

It is recommended that flexible collars be used to connect the main trunks to the heat pump. This helps prevent any vibrations from travelling down the ductwork. If a plenum heater is installed, the collar should be at least 12" away from the heater elements.

The first 5-10 feet of the main supply trunks should be insulated with acoustical duct insulation to further inhibit any noise from the unit from travelling down the ductwork. If a plenum heater is installed, insulation should not be placed within 12" of the heater elements.

DRAWING 001201CDG shows a typical installation.

DUCT SYSTEMS - GRILL LAYOUT

Most forced air heating systems in homes have the floor grills placed around the perimeter of the room to be heated. Supply grills should be placed under a window when possible to help prevent condensation on the window. As mentioned in the previous sub-section, supply grill leads should be 6" in diameter (28 sq.in. each) to allow **100cfm** of air flow.

In a typical new construction, there should be one supply grill for every 100sq.ft. of area in the room. When rooms require more than one grill, they should be placed in a manner that promotes even heat distribution, such as one at each end of the room. It is always a good idea to place a damper in each grill supply or place adjustable grills so that any imbalances in the heat distribution can be corrected.

The total number of supply grills available is based on the heat pump nominal airflow. **TABLE 8** shows the number of grills available per heat pump size.

TABLE 8 - Heat Pump Size vs. Hot Air Grills		
Model	Size (tons)	# of Grills (@100cfm)
25	2	8
45	3	12
55	4	15
65	5	19
75	6	21
80	6	24

Return grills should be mounted on the floor. At minimum they should be the same size as the supply grill, **it is highly recommended that they be 25% to 50% larger than the total supply.** They should be placed opposite the supply grills when possible to ensure distribution across the room. For rooms requiring more than one supply grill, it may be possible to use one larger return grill if it can be centrally positioned opposite of the supply grills, however it is preferred to have one return for each supply to maximize heat distribution across the room.

THERMOSTAT LOCATION

Most homes are a single zone with one thermostat. The thermostat should be centrally located within the home, typically on the main floor. It should be placed away from any supply grills, and should not be positioned directly above a return grill. Most installations have the thermostat located in a hallway, or in the inner wall of the living room. It should be noted that most homes do not have any supply ducts in the hallway. This can lead to a temperature lag at the thermostat if there is very little air movement in the hallway, causing the home to be warmer than indicated by the thermostat.

PLENUM HEATER (OPTIONAL)

For installations that do not already have a backup heat source such as electric baseboard, wood stove, propane etc, it is recommended that a plenum heater be installed. This provides two functions.

The first function of the plenum heater is to act as an auxiliary heat source. As such it will provide additional heat on extremely cold days if the heat pump is unable to bring the home temperature up quickly enough, eliminating any discomfort to the homeowner.

The second function of the plenum heater is to provide emergency heat should a problem occur that causes the heat pump to be locked out. This can be engaged by setting the thermostat to emergency heat, allowing the plenum heater to function while preventing the heat pump from operating. Should the heat pump fail while the home is vacant, the auxiliary function of the thermostat will maintain the temperature setting of the thermostat.

INSTALLATION—Fan outlet at top of unit: The heat pump comes equipped with an internal mounting location for the plenum heater. Remove the screws from the cover plate, remove the cover plate and place the plenum heater in the hole. Secure it in place with the cover plate screws. Use the indicated knock-outs on the heat pump case for electrical connections.

When installation is complete, check the appropriate box of the label on the unit door to indicate which size heater was installed.

INSTALLATION—Fan outlet at side of unit: The plenum heater should be installed in the supply duct in a manner that allows all of the airflow to pass through it to prevent any hot spots in the heater elements. Ensure that the plenum heater is mounted in an approved position as per its instructions.

Only two control wires are needed to connect the plenum heater to the heat pump terminal strip. Refer to the label on the plenum heater or the electrical box diagram on the inside of the electrical box cover of the **compressor unit** for details on the connections.

The plenum heater requires its own separate power supply. **TABLE 9** shows the recommended size plenum heater, as well as the wire size and breaker size needed to provide power to the plenum heater. Refer to the [Electrical Tables](#) for electrical connection information.

TABLE 9 - Plenum Heater Sizing			
Heat Pump	Plenum Heater Sizes (kW)		
Model Size	Recommended	Available	
25	7	5	
45	10	7	
55	10	7	15
65	15	10	20
75 - 80	20	15	


CONDENSATE DRAIN

The unit comes equipped with a 3/4" PVC socket fitting (female) labeled "Condensate Drain". This drain allows the condensate which forms during the air-conditioning cycle to be removed from the unit. The drain should be connected as per local codes. During high humidity weather, there could be as much as 25 gallons of water formed per day.

Care should be taken in the spring to ensure that this pipe is not plugged with dust that has collected during the winter causing the condensate to overflow into the bottom of the heat pump and onto the floor. **The condensate drain is internally trapped; however, proper venting is required external to the heat pump. Refer to local codes to ensure the installation is done properly.**

DRAWING 001201CDG shows a typical installation.

Typical Duct and Condensate Connections (Modular Case)



					Drawn By Chris Geddes	Date 22 JAN 09	<div>MARITIME GEOTHERMAL LTD.</div> <div>170 Plantation Rd. Petitcodiac, NB E4Z 6H4</div>			
					Checked By Chris Geddes	Date 22 JAN 09				
					Approved By Chris Geddes	(ENG) Date 22 JAN 09	Drawing Name Typical Duct and Condensate Connections (Modular Case)			
					Approved By Chris Geddes	(MFG) Date				
01	Initial Release	C. GEDDES	C. GEDDES	22 JAN 09	Approved By	Date	Size A	Drawing Number 001201CDG	REV 01	SHEET 1 of 1
REV	ECO #	IMPL BY	APVD BY	DATE						

TABLE 10 - Duct Sizing Guide (external static of 0.20"H2O)

Airflow (CFM)	Minimum Duct Area (sq.in)	Diameter (in)	Rectangular Equivalents (in)						Return Air Diameter (in)	Airflow (L/s)
37	20	5	2.25 x 10	3 x 8	3.5 x 6	4 x 5.5	5 x 5		← 5	17
63	20	5	2.25 x 10	3 x 8	3.5 x 6	4 x 5.5	5 x 5		↗ 6	30
100	28	6	3.25 x 10	4 x 8	5 x 6	5.5 x 5.5	6 x 6		← ↗ 7	47
152	38	7	3.25 x 14	4 x 11	5 x 8.5	6 x 7	6.5 x 6.5		← ↗ 8	72
212	50	8	4 x 15	5 x 12	6 x 10	7 x 8	8 x 8		← ↗ 9	100
226	50	8	4 x 15	5 x 12	6 x 10	7 x 8	8 x 8		↗ 10	107
277	64	9	5 x 15	6 x 12	7 x 10	8 x 9	8.5 x 8.5		← ↗ 10	131
304	64	9	5 x 15	6 x 12	7 x 10	8 x 9	8.5 x 8.5		↗ 12	143
393	79	10	6 x 15	7 x 13	8 x 11	9 x 10	9.5 x 9.5		← ↗ 12	185
411	113	12	7 x 18	8 x 16	9 x 14	10 x 12	11 x 11		← 12	194
655	113	12	7 x 18	8 x 16	9 x 14	10 x 12	11 x 11		↗ 14	309
680	154	14	8 x 22	9 x 19	10 x 17	11 x 15	12 x 14	13 x 13	← 14	321
995	154	14	8 x 22	9 x 19	10 x 17	11 x 15	12 x 14	13 x 13	↗ 16	470
1325	201	16	8 x 30	10 x 22	12 x 18	14 x 16	15 x 15		← ↗ 18	625
1450	201	16	8 x 30	10 x 22	12 x 18	14 x 16	15 x 15		↗ 20	684
1750	254	18	8 x 40	10 x 30	12 x 24	14 x 20	16 x 17	16.5 x 16.5	← ↗ 20	826
2000	254	18	8 x 40	10 x 30	12 x 24	14 x 20	16 x 17	16.5 x 16.5	↗ 22	944
2250	314	20	10 x 38	12 x 30	14 x 26	16 x 22	18 x 19	18.5 x 18.5	← ↗ 22	1062
2600	314	20	10 x 38	12 x 30	14 x 26	16 x 22	18 x 19	18.5 x 18.5	↗ 24	1227
2900	380	22	12 x 36	14 x 30	16 x 26	18 x 23	20 x 20		← ↗ 24	1369
3400	380	22	12 x 36	14 x 30	16 x 26	18 x 23	20 x 20		↗ 26	1605
3600	452	24	14 x 38	16 x 32	18 x 28	20 x 25	22 x 22		← ↗ 26	1699
4300	452	24	14 x 38	16 x 32	18 x 28	20 x 25	22 x 22		↗ 28	2029
5250	531	26	16 x 38	18 x 32	20 x 30	22 x 24	24 x 24		← ↗ 30	2478
6125	616	28	18 x 38	20 x 34	22 x 30	24 x 28	26 x 26		← ↗ 32	2891
6500	616	28	18 x 38	20 x 34	22 x 30	24 x 28	26 x 26		↗ 34	3068
7250	707	30	20 x 40	22 x 38	24 x 32	26 x 30	28 x 28		← ↗ 34	3422
7800	707	30	20 x 40	22 x 38	24 x 32	26 x 30	28 x 28		↗ 36	3681
8500	804	32	22 x 40	24 x 38	26 x 34	28 x 32	30 x 30		← ↗ 36	4012
9200	804	32	22 x 40	24 x 38	26 x 34	28 x 32	30 x 30		↗ 38	4342
9800	908	34	24 x 42	25 x 40	26 x 38	28 x 34	30 x 32	31 x 31	← ↗ 38	4625
10900	908	34	24 x 42	25 x 40	26 x 38	28 x 34	30 x 32	31 x 31	↗ 40	5144
			28 x 40	30 x 36	32 x 34	33 x 33			← ↗	
			30 x 42	32 x 38	34 x 36	35 x 35			← ↗	
			30 x 45	34 x 40	36 x 38	37 x 37			← ↗	

Ground Water System Information

GENERAL REQUIREMENTS

1. The temperature of the well water should be a minimum of **39°F (4°C)**, and should normally be **45+°F (7°C)**
2. The well system must be able to supply the required water flow as listed under the Total Flow column in **TABLE 11**.

TABLE 11 - Required Flow and Air Tank Sizing				
Heat Pump Model Size	Heat Pump Flow* USGPM (L/s)	Home Flow USGPM (L/s)	Total Flow USGPM (L/s)	Minimum Air Bladder Tank** USgal (L)
25	7.0 (0.44)	4 (0.25)	11 (0.69)	22 (83)
45	10.0 (0.63)	4 (0.25)	14(0.88)	28 (106)
55	12.0 (0.76)	4 (0.25)	16(1.01)	32 (121)
65	14.0 (0.88)	4 (0.25)	18(1.14)	36 (136)
75	16.0 (1.01)	4 (0.25)	20 (1.26)	40 (151)
80	17.0 (1.07)	4 (0.25)	21(1.32)	42 (159)
* These are minimum water requirements based on an entering water temperature of 46° F.				
**Based on two-minute well pump run time. Use next size larger tank if there is not a match for the value indicated. A larger tank may be used if a longer run time is desired.				

PLUMBING THE HEAT PUMP

The port connections for the Outdoor Loop are 1" brass FPT fittings. They are marked as OUTDOOR IN and OUT.

Plumbing lines, both IN (supply) and OUT (discharge), must be of adequate size to handle the water flow necessary for the heat pump. A 1" copper or plastic line should be run to the Outdoor IN (Supply IN) pipe of the heat pump. Similarly, a 1" line should be run from the Outdoor OUT (Supply Out) pipe to the method of disposal. P/T plugs should be installed at each port. See **Diagram A** in the Ground Loop section for a description of P/T plugs. The water valve should be installed in the OUT (discharge) line. **Refer to drawing 000907CDG at the end of this section** for the recommended setup. Placing the water valve in the discharge line ensures that the heat exchanger inside the heat pump remains full of water when the unit is not running. Unions or some other form of disconnect should be used so that the coaxial heat exchanger may be accessed should it required cleaning.

The heat pump has an electrical connector for the water valve just inside the case. After the water valve is installed, run the valve harness into the case through the hole provided. Remove the jumper plug from the Valve Connector and connect the harness in its place.

Ideally there will be water flow available in excess of the requirement of the heat pump. In such a situation the proper pump can be selected to maintain a pressure of 30 to 40 psig. on the lines when the heat pump is operating. However in some cases a well can supply a heat pump only if the minimum requirement for water is used.

Water flow to the heat pump can be controlled very accurately by the installation of a reverse action refrigeration pressure valve in the discharge line of the unit.

Another more common method of regulating the flow is by the use of a **DOLE** Valve. This valve will automatically control the amount of water flowing through it by varying the diameter of a flexible rubber orifice through which the water passes. This minimizes the water usage of the unit and also prevents excessively low discharge pressure when in cooling mode. Dole valves can be noisy, it is recommended that they be installed outside if possible.

Optionally a water flow meter can be installed in the discharge line so that the exact amount of water flowing can be determined at a glance. It should be placed between the Outdoor OUT (Supply OUT) pipe of the heat pump and the water valve.

With Proper flow, there should be **5-7°F (3-4°C)** delta T between the IN and OUT water temperatures of the heat pump when operating in the heating mode.

All water line valves on both the supply and discharge lines should be either BALL or GATE valves. GLOBE valves have a higher pressure drop, meaning more pumping power to maintain the required flow to the heat pump.

PIPE INSULATION

All ground water piping to and from the Outdoor Loop ports on the heat pump should be insulated with 3/8" closed cell pipe insulation, to prevent condensation and dripping onto floors or walls.

WATER DISCHARGE METHODS

Water disposal methods vary from area to area. However, some consideration should be made to prevent the cooled discharge water from immediately coming in contact with the supply source. Attempting to return the water to the source well will eventually cool the water so much that the heat pump will shut off on its low pressure safety control.

Acceptable methods for disposing of the waste water are listed below. The waste water is clean, the heat pump has no effect other than reducing the temperature of the water. **Refer to drawing 000907INF** for typical disposal method diagrams.

- Second well (return well)
- Percolation (Drain, ditch, leaching field)
- Pond, river or stream.

ENSURE SELECTED METHOD CONFORMS TO LOCAL CODES.


A return well should be a minimum of **80 ft.** from the supply well for residential applications. The water returned to the well will not necessarily be pumped into the same aquifer, depending on underground conditions. The return well must be able to supply at least the same quantity of water as the amount you wish to recharge into it. If the static level (level when not being pumped) of a well is high (10 to 20 ft. from the surface) it may be necessary to place a well cap on the well to keep the return water from flowing out the top of the well. This cap is commonly required since a certain amount of pressure is needed to force the return water back down the well if the static level is high.

Water discharged by percolation will generally soak into the ground within a distance of 50 to 100 ft. If suitable care is taken to ensure that the drain pipe runs downhill and the end of the pipe is protected by a bale of hay or spruce bows etc. the end of the pipe will not freeze as the pipe will empty out when the heat pump shuts off and the water valve closes.




When snow comes it will usually cover the entire process much like a small spring. It is recommended that the pipe be below the frost line when possible for maximum freeze protection.

When discharging into a river or stream, or above the surface of a pond, the same guidelines should be followed as described in the paragraph above for the percolation method.

When discharging the waste water below the surface of a pond, the discharge pipe should be placed below the frost line to prevent the pipe from freezing. As opposed to the percolation method, water will remain in the end of the pipe. It is recommended that the surface of the pond be lower than the installation location of the heat pump where practical. This reduces the back pressure generated by the weight of the water in the pond.



GROUND WATER DISPOSAL METHODS



					Drawn By Chris Geddes	Date 04 FEB 08	MARITIME GEOTHERMAL LTD.		170 Plantation Rd. Petitcodiac, NB E4Z 6H4	
					Checked By Chris Geddes	Date 04 JAN 08				
					Approved By (ENG) Chris Geddes	Date 04 FEB 08	Drawing Name Ground Water Disposal Methods			
					Approved By (MFG)	Date				
01	Initial Release	C. GEDDES	C. GEDDES	04 FEB 08	Approved By	Date	Size A	Drawing Number 000619INF	REV 01	SHEET 1 of 1
REV	ECO #	IMPL BY	APVD BY	DATE	Approved By	Date				

Ground Loop System Information

Once the ground loop has been pressure tested and the header pipes have been connected to the circulator pump module, the heat pump can be connected to the circulator pump module.

The port connections for the Outdoor Loop are 1" brass FPT fittings. They are marked as OUTDOOR IN and OUT.


CIRCULATOR PUMP MODULE

Maritime Geothermal Ltd. has compact pump modules with built in three way valves to facilitate filling and purging the ground loop. **Refer to drawing 000906CDG at the end of this section.** Alternatively, Grundfoss® Model UPS 26-99 or Taco® Model 0011 pumps or other brands with similar pumping capability may be used. The single pump module will typically handle systems up to 3 tons (model sizes 25, 35, and 45); the two pump module will typically handle 4 to 6 ton systems (model sizes 55, 65, 75, 80). This is based on a typical parallel system with one circuit per ton.

Maritime Geothermal recommends calculating the total pressure drop of the ground loop (including headers, indoor piping and heat pump exchanger drop) based on the antifreeze type and concentration at the desired minimum loop temperature. A pump module that can deliver the flow required for the unit at the calculated total pressure drop should be selected. **Refer to the Model Specific Information section** for unit flow requirements.

Loop pressure drops can be calculated using software such as those mentioned in the Horizontal Ground loops section, or can be calculated in a spreadsheet using the pipe manufacturer's pressure drop tables for pipe diameter and fittings.

The circulator pump module must be connected to the heat pump Outdoor Loop ports with a lineset suitable for the flow required with minimum pressure drop. 1" rubber or plastic lines should be used. The installation of P/T plugs (pressure / temperature, pronounced "Pete's plugs") is recommended on both the entering and leaving lines at the heat pump (**see Diagram A**).




The P/T plug will allow the installer or homeowner to check water flow through the loop by measuring the pressure difference through the heat exchanger and comparing it to that listed in the **Model Specific Information section**, or the specifications document. Optional fittings with P/T ports are available for the circulator pump modules sold by Maritime Geothermal Ltd..

FLUSHING & PURGING THE GROUND LOOP

Once the groundloop has been installed and all connections are completed between the heat pump, circulator pump module and ground loop, the entire ground loop system should be **pressure tested with air to 100 PSIG** to make sure there are no leaks on any of the inside fittings. Soap all joints and observe that the pressure remains constant for 1 hour.

When satisfied that all connections are leak free, release the air pressure and connect a purge cart (**see Diagram B**) to the flushing access ports at the pump module (**refer to drawing 000906CDG**). A temporary flushing system can alternately be constructed using a 45 gal. barrel and a pump with sufficient volume and head capability to circulate fluid at a **velocity of at least 2 ft./min.** through all parts of the loop.



Adjust the circulator pump module valves to connect the purge cart to the ground loop. Begin pumping water through the ground loop, ensuring that the intake of the pump stays submerged at all times by continuously adding water. Water flowing back from the return line should be directed below the water level in the barrel or flush tank to prevent air being mixed with the outgoing water.

Once the lines have been filled and no more air bubbles are appearing in the line, adjust the circulator pump module valves to circulate water through the heat pump using the same technique as described above. When all air is removed reverse the flow of water through the lines by interchanging the flush cart lines and purge again. You will be able to visibly tell when all air is removed.

ADDING ANTIFREEZE SOLUTION

In most mid and northern areas of the US and in all of Canada it is necessary to condition the loop fluid by the addition of some type of antifreeze solution so that it will not freeze during operation in the winter months. This antifreeze is required because the loop fluid will normally reach a low entering temperature of **28°F to 32°F (-2°C to 0°C)** and refrigerant temperatures inside the heat pump's heat exchanger may be as low as **20°F (11°C)** cooler. See **TABLE 12** for details of freeze protection provided by different concentrations.

TABLE 12 - Antifreeze Percentages				
BY VOLUME				
Protection to:	10°F	15°F	20°F	25°F
Methanol	25%	21%	16%	10%
Propylene Glycol	38%	30%	22%	15%
BY WEIGHT				
Protection to:	10°F	15°F	20°F	25°F
Methanol	16.8%	13.6%	10%	6.3%
Propylene Glycol	30%	23.5%	18.3%	12.9%



WARNING: Add enough antifreeze to allow for a temperature 20°F (11°C) lower than the expected lowest loop fluid temperature entering the heat pump. Insufficient antifreeze concentration could cause the heat exchanger to freeze and rupture, voiding the warranty.

Although many different antifreeze solutions have been employed in geothermal systems, the alcohols such as methanol or ethanol have the most desirable characteristics for groundloop applications. The overall heat transfer characteristics of these fluids remain high although care must be taken when handling pure alcohols since they are extremely flammable. Once mixed in a typical 25% by volume ratio with water the solution is not flammable. In situations where alcohols are not allowed as a loop fluid due to local regulations then propylene glycol is a non-toxic alternative which can be substituted. Propylene glycol should only be used in cases where alcohols are not permitted since the heat transfer characteristics are less desirable and it becomes more viscous at low temperatures, increasing pumping power.

The volume of fluid that your loop system holds can be closely estimated by totaling the number of ft. of each size pipe in the system and referencing **TABLE 13** the for approximate volume per 100 ft.

When the volume of the loop has been calculated and the appropriate amount of antifreeze is ready for addition by referencing **TABLE 12**, drain the equivalent amount of water from the flush cart or mixing barrel and replace it with the antifreeze.

TABLE 13 - Volume of fluid per 100 ft. of pipe

		Volume /100ft.		
Type of Pipe	Diameter	Igal	USgal	L
Copper	1"	3.4	4.1	15.5
	1-1/4"	5.3	6.4	24.2
	1-1/2"	7.7	9.2	34.8
Rubber Hose	1"	3.2	3.9	14.8
Polyethylene	3/4" IPS SDR11	2.3	2.8	10.6
	1" IPS SDR11	3.7	4.5	17.0
	1-1/4" IPS SDR11	6.7	8.0	30.3
	1-1/2" IPS SDR11	9.1	10.9	41.3
	2" IPS SDR11	15.0	18.0	68.1
Other Item Volumes				
Heat Exchanger	Average	1.2	1.5	5.7
Purge Cart Tank	See cart manual	TBD		

When using alcohols, be sure to inject below the water line to reduce initial volatility of the pure antifreeze. If the loop is large it may be necessary to refill the tank with antifreeze several times to get all the antifreeze into the loop. Pump the loop for 5 to 10 minutes longer to ensure the remaining fluid has been well mixed.

INITIAL PRESSURIZATION

At this point open all valves in the flow circuit and slowly close off the supply and return flush cart valves in a manner that leaves about **20-30 psig.** on the system. If an air bladder expansion tank is used it should be charged to the above pressure before actual water pressure is put on the system. Systems without an expansion tank will experience greater fluctuations in pressure between the heating and cooling seasons, causing pressure gauges to have different values as the loop temperature changes. This fluctuation is normal since expansion and contraction of the loop fluid must be handled by the elasticity of the plastic loop.

- Pressurize the loop to a static pressure of **45 psig.** when installing a system in the fall going into the heating season.
- Pressurize the loop to a static pressure of **25 psig.** when installing a system in the spring or summer going into the cooling season.

After operating the heat pump for a period of time, any residual air in the system should be bled off and the static pressure should be verified and adjusted if necessary. Add additional water / antifreeze mix with the purge cart to bring the pressure back to the original setting if required.

PIPE INSULATION

All ground loop piping inside the structure (between the structure entry point and the heat pump) should be insulated with 3/8" thick closed cell pipe insulation to prevent condensation and dripping onto floors or walls.


Geo-Flo Circulator Pump Module Installation (Units with Brass FPT Fittings)

2911 - 1" to 1-1/4" PE Socket

1" Fill & Purge access ports
2914 Camlocks can be used for quick connections. Fittings can be removed and reused on other jobs when purging is complete

Connect wiring to appropriate voltage terminals marked **OUTDOOR CIRCULATORS** in the heat pump electrical box

NOTE:
Refer to the heat pump labels for connection locations



Available Fittings:
3144 - 1" Sweat (optional P/T)
2913 - 1" Barbed
3072 - 1" MPT


Basement Wall
1-1/4" PE 3408
Fill gap between insulation and wall with expanding foam

NOTES:


- Circulator Pump Module should be mounted vertically to minimize the possibility of air locking the circulators.
- All lines inside the structure and through the wall should be insulated with 3/8" to 1/2" thick closed cell pipe insulation.
- Holes through the foundation / structure should be filled with expanding foam from both sides to prevent leakage.
- Proper drainage material should be used on the outside of the wall to prevent water buildup.
- Pump module fittings are available from Maritime Geothermal Ltd., Geo-Flo Part Numbers are indicated above (italics).
- A pressure gauge is recommended if P/T plugs are not installed.
- The air bladder tank should be pressurized to the desired static pressure of the ground loop before installation.
- For most applications, a 1 pump module will accommodate model sizes 09 to 45, and a 2 pump module will accommodate sizes 55 to 80. The total loop pressure drop including the headers, inside piping and heat exchanger drop should be calculated based on the antifreeze mixture and lowest desired entering water temperature. The pump module selected must provide the required flow at this calculated pressure drop value.

CIRCULATOR PUMP MODULE 3-WAY VALVE POSITIONS (LEFT SIDE VIEW)


1. Valve in Loop fill/purge position.



2. Valve in HP fill/purge position



3. Valve in normal running position.



					Drawn By Chris Geddes	Date 09 DEC 08	MARITIME GEOTHERMAL LTD. 170 Plantation Rd. Petitcodiac, NB E4Z 6H4		
					Checked By Chris Geddes	Date 09 DEC 08			
					Approved By Chris Geddes (ENG)	Date 09 DEC 08	Drawing Name Geo-Flo Circulator Pump Module Installation (Brass FPT)		
					Approved By Chris Geddes (MFG)	Date			
					Approved By	Date	Size A	Drawing Number 000906PDG	Drawing Rev 02
02	000213	C. GEDDES	C. GEDDES	21 MAY 2013					
01	Initial Release	C. GEDDES	C. GEDDES	09 DEC 2008					
REV	ECO #	IMPL BY	APVD BY	DATE					

Startup Procedure

The following steps describe how to perform the startup procedure of the geothermal heat pump.

The R-Series Two-Stage R410a Startup Record located in this manual is used in conjunction with this startup procedure to provide a detailed record of the installation. A completed copy should be left on site, a copy kept on file by the installer and a copy should be sent to Maritime Geothermal Ltd.

Check the boxes or fill in the data as each step is completed. For data boxes, circle the appropriate units. Fill in the top section of all three copies, or one copy if photocopies can be made after the startup has been completed.

PRE-START INSPECTION

Ductwork:

1. Verify that all ductwork has been completed and is firmly attached to the unit. Verify that any dampers or diverters are properly set for operation of the heat pump.
2. Verify that all registers are open and clear of any objects that would restrict the airflow.
3. Verify that a new air filter is installed and the cover is secured.
4. Verify the condensate drain is connected, properly vented and free of debris.
5. If a plenum heater has been installed, verify that it is securely fastened to the ductwork.

Outdoor Loop (Ground Loop):

1. Verify that all shutoff valves are fully open and there are no restrictions in the piping from the heat pump to the ground loop, and that full flow is available to the heat pump.
2. Verify that the entire system has been flooded and all the air has been purged as much as possible. Further purging may be required after the system has been operating for a while.
3. Verify that the loop contains the proper mix of antifreeze for the intended application. Record the type of antifreeze and the mixture value on the startup sheet; circle % Vol. or % Weight.
4. Record the static loop pressure on the startup sheet.

Outdoor Loop (Ground Water):

1. Verify there are no leaks in the connections to the unit. Verify the water valve is installed and properly oriented in the return line.
2. Verify that there is flow control in the return line.

Domestic Hot Water (if equipped):

1. Verify that all shutoff valves are fully open and there are no restrictions in the piping from the heat pump to the domestic hot water tank.
2. Verify that the entire system has been flooded and all the air has been purged as much as possible. Further purging may be required after the system has been operating for a while.
3. Verify that the brown wire with the insulated terminal is disconnected in the electrical box. Refer to the schematic diagram for more information.

Electrical:

1. **Ensure the power to the unit is off. Ensure the power to the plenum heater is off if equipped.**
2. Verify all high voltage connections. Ensure that there are no stray wire strands, all connections are tight and the ground wire is connected tightly to the ground connector for the heat pump and plenum heater.
3. Record the fuse / circuit breaker size and wire gauge for the heat pump. Record the fuse / circuit breaker size, wire gauge and size of the plenum heater if installed.
4. Verify that the control connections to the thermostat and plenum heater (if installed) are properly connected and all control signals are off, so that the unit will not start up when the power is turned on.
5. Ensure all access panels except the lower one that provides access to the electrical box are in place.

UNIT STARTUP

The unit is now ready to be started. The steps below outline the procedure for starting the unit and verifying proper operation of the unit. **It is recommended that safety glasses be worn during the following procedures.**

Preparation:

1. Remove the caps from the service ports and connect a refrigeration manifold set to the unit.
2. Turn the power on to the heat pump and set the thermostat to OFF. Set up the thermostat as per the instructions provided with it so that it will function properly with the heat pump system (set for heat pump, not for heating and cooling). The O signal should be set to active in cooling mode.
3. Measure the following voltages on the compressor contactor and record them on the startup sheet: L1-L2, L2-L3, L1-L3.

Heating Mode:

1. Set the thermostat to heating mode and adjust the setpoint to activate Stage 1 and Stage 2. The fan should slowly ramp up to speed after the time delay of the thermostat expires (if applicable) and the compressor will start (allow 30-60 seconds for the water valve to open for ground water systems)
2. Check the refrigeration gauges. The suction and discharge pressures will depend on the loop temperatures, but they should be about **90-110PSIG** and **260-360PSIG** respectively for a typical start-up.
3. Monitoring the refrigeration gauges while the unit runs. Record the following after 10 minutes of runtime:
 1. Suction pressure
 2. Discharge pressure
 3. Duct Return temperature (poke a small hole in the flex collar and insert probe in airstream)
 4. Duct Supply temperature (poke a small hole in the flex collar and insert probe in airstream)
 5. Duct Delta T (should be between **22-32°F, 12-18°C**)
 6. Outdoor Loop In (Supply In) temperature
 7. Outdoor Loop Out (Supply Out) temperature
 8. Outdoor Delta T (should be between **5-8°F, 3-4°C**)
 9. Outdoor flow (if available)
 10. Compressor L1(C) current (black wire, place meter between electrical box and compressor)
4. Adjust the thermostat setpoint to the desired room temperature and let the unit run through a cycle. Record the setpoint, Suction, and discharge pressures when the unit shuts off.
5. For units with a desuperheater, turn the power off to the unit. Connect the brown wire with the blue insulated terminal to the compressor contactor as shown in the electrical box diagram. Turn the DHW Switch in the unit post on. Turn the power to the unit on.
6. Remove the electrical cover from the plenum heater. Place a current clamp meter around one of the supply wires. Turn on the power to the plenum heater. Adjust the thermostat setpoint to **85°F (29°C)**. Verify that the current draw increase as each stage is activated. (10kW has 2 stages, 15kW has 3 stages and 20kW has 4 stages).
7. Verify the DHW IN and DHW OUT temperatures (if applicable) by hand (**caution: pipes get hot**). If the DHW OUT line does not become hotter than the DHW IN line the circulator is air locked. Bleed the air from the system and check the temperature differential again to ensure there is flow from the circulator.

Cooling Mode:

1. Set the thermostat to cooling mode and adjust the setpoint to activate Stage 1 and Stage 2.
2. Monitoring the refrigeration gauges while the unit runs. Record the following after 10 minutes of runtime:
 1. Suction pressure
 2. Discharge pressure
 3. Duct Return temperature
 4. Duct Supply Out temperature
 5. Duct Delta T
 6. Outdoor Loop In (Supply In) temperature
 7. Outdoor Loop Out (Supply Out) temperature
 8. Outdoor Delta T
3. Adjust the thermostat setpoint to the desired room temperature if possible, otherwise set it just low enough to allow the unit to run (ie 1°F (0.5°C) less than room temperature) and let the unit run through a cycle. Record the thermostat setpoint, suction pressure and discharge pressure when the unit shuts off.

Final Inspection:

1. Turn the power off to the unit (and plenum heater if installed) and remove all test equipment.
2. Install the electrical box cover and the access panel on the heat pump. Install the service port caps securely to prevent refrigerant loss. Install the electrical cover on the plenum heater if applicable.
3. Do a final check for leaks in the ground water / ground loop system and ensure the area is clean.
4. Turn the power on to the unit and the plenum heater if installed. Set the thermostat to the final settings.

Startup Record:

1. The installer shall sign and date the Startup Record and have the homeowner sign as well. The installer shall leave the Startup Record with the homeowner, retain a copy for filing and send a copy to Maritime Geothermal Ltd. for warranty registration.

Startup Record —R-Series Size 25-80 Two-Stage R410a

Installation Site		Startup Date	Installer	
City			Company	
Province			Model	
Country			Serial #	
Homeowner Name		Homeowner Phone #		

Check boxes unless asked to record data. Circle data units.

PRE-START INSPECTION

Ductwork	Ductwork is completed, dampers/ diverters are adjusted										
	Registers are open and clear of objects										
	Air filter and end cap are installed										
	Condensate Drain is connected, properly vented and free of debris										
	Plenum heater is securely fastened (if applicable)										
Ground Loop System	All shut-off valve are open (full flow available)										
	Loop is full and purged of air										
	Antifreeze type										
	Antifreeze concentration		% Volume	% Weight							
	Loop static pressure		PSI	kPa							
Ground Water System	Water Valve installed in return line										
	Flow control installed in return line										
Domestic Hot Water	All shut-off valves are open										
	Lines are full and purged										
	Desuperheater pump wire is disconnected										
Electrical	High voltage connections are correct and securely fastened										
	Circuit breaker (or fuse) size and wire gauge for Heat Pump						A		Ga.		
	Circuit breaker (or fuse) size, wire gauge, and Plenum Heater size						A		Ga.		kW
	Low voltage connections are correct and securely fastened										

STARTUP DATA

Preparation	Voltage across L1 and L2, L1 and L3, L2 and L3					VAC
Heating Mode (10 minutes)	Suction Pressure / Discharge Pressure				psig	kPa
	Duct Return, Duct Supply, and Delta T		In		Out	°F °C
	Outdoor In (Supply In), Outdoor Out (Supply Out), and Delta T		In		Out	°F °C
	Outdoor Flow		lgpm	USgpm	L/s	
	Compressor L1 (black wire) current		A			
	Domestic Hot Water functioning					
	Thermostat setpoint, suction and discharge pressures at cycle end		°F	°C		psig
Cooling Mode (10 minutes)	Suction Pressure / Discharge Pressure				psig	kPa
	Duct Return, Indoor Out, and Delta T		In		Out	°F °C
	Outdoor In (Supply In), Outdoor Out (Supply Out), and Delta T		In		Out	°F °C
	Thermostat setpoint, suction and discharge pressures at cycle end		°F	°C		psig

Date:		Installer Signature:		Homeowner Signature:	
--------------	--	-----------------------------	--	-----------------------------	--

A total of three copies are required, one for the homeowner, one for the installer and on to be sent to Maritime Geothermal Ltd.

General Maintenance

GENERAL MAINTENANCE SCHEDULE		
Item	Interval	Procedure
Air Filter	6 months	Inspect for dirt. Replace if necessary.
Contactor	1 year	Inspect for pitted or burned points. Replace if necessary.
Condensate Drain	1 year	Inspect for clogs. Remove and clean if necessary.
Heat exchanger	As required*	Clean as per HEAT EXCHANGER FLUSHING PROCEDURE below.
*Generally not required for closed loop systems. Whenever system performance is reduced for open loop.		

COAXIAL HEAT EXCHANGER FLUSHING PROCEDURE—GROUNDWATER	
STEP 1	Isolate the heat exchanger by closing the valves in the IN and OUT ports to the heat exchanger.
STEP 2	Blow out the heat exchanger into a clean 5 gallon bucket using compressed air.
STEP 3	If a purge cart is not available, use a 5 gallon plastic bucket, a circulator and some plastic piping to create a makeshift pump system. Connect a the inlet and outlet to the heat exchanger ports.*
STEP 4	Place 2 gallons of RYDLYME in the purge cart (or bucket). Circulate the fluid through the heat exchanger for at least 2 hours (3 recommended).
STEP 5	Disconnect the purge system dispose of the solution. RYDLYME is non-toxic and biodegradable and as such can be poured down a drain.
STEP 6	Connect fresh water and a drain to the heat exchanger ports and flush the exchanger for several minutes.
STEP 7	Return the plumbing to its original configuration and open the IN and OUT valves. Operate the system and check for improved performance.
*Depending on the plumbing, there should be either unions or boiler drains for to access the heat exchanger.	

COAXIAL HEAT EXCHANGER FLUSHING PROCEDURE—GROUND LOOP	
STEP 1	Isolate the heat exchanger by placing the pump module valves in the exchanger flushing position.
STEP 2	Connect a compressed air and a drain pipe to the pump module purge ports and blow the anti-freeze solution into a clean 5 gallon bucket.
STEP 3	Connect a purge cart to the pump module purge ports.
STEP 4	Place 2 gallons of RYDLYME in the purge cart. Circulate the fluid through the heat exchanger for at least 2 hours (3 recommended).
STEP 5	Disconnect the purge cart and dispose of the solution. RYDLYME is non-toxic and biodegradable and as such can be poured down a drain. Clean the purge cart thoroughly.
STEP 6	Connect fresh water and a drain to the pump module purge ports and flush the exchanger for several minutes.
STEP 7	Blow the heat exchanger out with compressed air as per STEP 2 and dump the water down a drain.
STEP 8	Connect the purge cart to the pump module purge ports. Re-fill and purge the heat exchanger with as per standard procedures (the anti-freeze from STEP 2 can be re-used).
STEP 9	Disconnect the purge cart and set the pump module valves back to the original positions.
STEP 10	Operate the system and check for improved performance.
*Depending on the plumbing, there should be either unions or boiler drains for to access the heat exchanger.	

Troubleshooting Guide

The following steps are for troubleshooting the geothermal heat pump. If the problem is with the domestic hot water or the plenum heater, proceed to those sections at the end of the troubleshooting guide. Repair procedures and reference refrigeration circuit diagrams can be found at the end of the troubleshooting guide.

- STEP 1:** Verify that the display is present on the thermostat. If it is not, proceed to POWER SUPPLY TROUBLESHOOTING, otherwise proceed to STEP 2.
- STEP 2:** Remove the door and electrical box cover and check to see if there is a fault code on the control board. If there is, record the fault code. Turn the power off, wait 10 seconds and turn the power back on. Set the thermostat to call for heating or cooling depending on the season.
- STEP 3:** If a 24VAC signal does not appear across Y1 and C of the terminal strip within 6 minutes, proceed to the THERMOSTAT TROUBLESHOOTING section, otherwise proceed to STEP 4.
- STEP 4:** If a fault code appears once a signal is present at Y1 and the compressor does not attempt to start, proceed to the FAULT CODE TROUBLESHOOTING section, otherwise proceed to STEP 5.
- STEP 5:** If no fault codes appear and the compressor does not attempt to start, attempts to start but cannot, starts hard, or starts but does not sound normal, proceed to the COMPRESSOR TROUBLESHOOTING section, otherwise proceed to STEP 6.
- STEP 6:** If the compressor starts and sounds normal, this means the compressor is OK and the problem lies elsewhere. Proceed to the OPERATION TROUBLESHOOTING section.

NOTE: To speed up the troubleshooting process, the Test Jumper on the safety board can be placed to the YES position to change the anti-short cycle timer to 5 seconds. **Be sure to set it back to NO when servicing is complete.**

POWER SUPPLY TROUBLESHOOTING			
Fault	Possible Cause	Verification	Recommended Action
No power to the heat pump	Disconnect switch open (if installed)	Verify disconnect switch is in the ON position.	Determine why the disconnect switch was opened, if all is OK close the switch.
	Fuse blown / Breaker Tripped.	At heat pump disconnect box, voltmeter shows 230VAC on the line side but not on the load side.	Reset breaker or replace fuse with proper size and type. (Time-delay type "D")
No display on thermostat.	Transformer breaker tripped.	Breaker on transformer is sticking out.	Push breaker back in. If it trips again locate cause of short circuit and correct.
	Faulty transformer	Transformer breaker is not tripped, 230VAC is present across L1 and L3 of the compressor contactor but 24VAC is not present across R _H and C of the terminal strip.	Replace transformer.
	Faulty wiring between heat pump and thermostat.	24VAC is not present across C and R(R _H) of the thermostat.	Correct the wiring.
	Faulty Thermostat.	24VAC is present across C and R (R _H) of the thermostat but thermostat has no display.	Replace thermostat.

THERMOSTAT TROUBLESHOOTING			
Fault	Possible Cause	Verification	Recommended Action
No Y1 signal to heat pump (after 6 minutes)	Incorrect thermostat set-up.	Thermostat does not indicate a call for heat. No 24VAC signal present across C and Stage 1 of the thermostat	Correct the setup.
	Faulty thermostat to heat pump wiring.	24VAC signal present across Stage 1 and C of the thermostat but not present across Y1 and C of the terminal strip.	Correct or replace wiring
	Faulty thermostat.	No 24VAC between Stage 1 and C of the thermostat when a call is indicated on the thermostat.	Replace thermostat.

FAULT CODE TROUBLESHOOTING			
Fault	Possible Cause	Verification	Recommended Action
Fault Code 1 (High Pressure Control)	Faulty High Pressure Control (open). * Must be a signal present on Y1 for this test. *HP pressures must be at static levels.	Verify if there is 24VAC across HP1 on the control board and C of the terminal strip, as well as HP2 and C.	Replace high pressure control if voltage is present on HP1 but not on HP2.
	Faulty control board.	24VAC is present across HP1 and C1, and HP2 and C, but no voltage is present across CC on the control board and C.	Replace control board.
Fault Code 2 (Low Pressure Control)	Faulty Low pressure control (open). * Must be a signal present on Y1 for this test. *HP pressures must be at static levels.	Verify if there is 24VAC across LP1 on the control board and C of the terminal strip, as well as LP2 and C.	Replace high pressure control if voltage is present on LP1 but not on LP1.
	Faulty control board.	24VAC is present across LP1 and C, and LP2 and C, but no voltage is present across CC on the control board and C.	Replace control board.
	Unit out of refrigerant.	Check static refrigeration pressure of the unit for a very low value.	Locate the leak and repair it. Spray nine, a sniffer and dye are common methods of locating a leak.
Fault Code 3 (Flow Switch)	Flow switch jumper removed or faulty.	Verify jumper is in place between pins marked FLOW SWITCH.	Place a jumper if missing.
	Flow switch faulty. (Only if installed)	Verify 24VAC is present between each flow switch pin on the control board and the C terminal of the terminal strip while there is flow through the unit.	Replace flow switch if signal is not present at both terminals on the control board.
	Faulty control board.	24VAC is present across each FLOW SWITCH terminal and C, but not voltage is present across CC on the control board and C.	Replace control board.

COMPRESSOR TROUBLESHOOTING

Fault	Possible Cause	Verification	Recommended Action
Compressor will not start	Faulty control board.	Measuring from C on the terminal strip, verify there is voltage at Y, HP1, HP2, LP1, LP2, and both flow pins but no voltage present at CC.	Replace control board.
	Faulty run capacitor. (Single phase only)	Check value with capacitance meter. Should match label on capacitor. Compressor will hum while trying to start and then trip its overload.	Replace if faulty.
	Loose or faulty wiring.	Check all compressor wiring, including inside compressor electrical box.	Fix any loose connections. Replace any damaged wires.
	Faulty compressor contactor.	Voltage on line side with contactor held closed, but no voltage on one or both terminals on the load side. Points pitted or burned. Or, 24VAC across coil but contactor will not engage.	Replace contactor.
	Thermal overload on compressor tripped.	Ohmmeter shows reading when placed across R and S terminals and infinity between C & R or C & S. A valid resistance reading is present again after the compressor has cooled down.	Proceed to Operation Troubleshooting to determine the cause of the thermal overload trip.
	Burned out motor (open winding)	Remove wires from compressor. Ohmmeter shows infinite resistance between any two terminals. Note: Be sure compressor overload has had a chance to reset. If compressor is hot this may take several hours.	Replace the compressor.
	Burned out motor (shorted windings)	Remove wires from compressor. Resistance between any two terminals is below the specified value.	Replace the compressor.
	Motor shorted to ground.	Remove wires from compressor. Check for infinite resistance between each terminal and ground.	If any terminal to ground is not infinite replace the compressor.
	Seized compressor due to locked or damaged mechanism.	Compressor attempts to start but trips its internal overload after a few seconds. (Run capacitor already verified)	Attempt to "rock" compressor free. If normal operation cannot be established, replace compressor.
Compressor starts hard	Start capacitor faulty. (Single phase only)	Check with capacitance meter. Check for black residue around blowout hole on top of capacitor.	Replace if faulty. Remove black residue in electrical box if any.
	Potential Relay faulty. (Single phase only)	Replace with new one and verify compressor starts properly.	Replace if faulty.
	Compressor is "tight" due to damaged mechanism	Compressor attempts to start but trips its internal overload after a few seconds. Run capacitor has been verified already.	Attempt to "rock" compressor free. If normal operation cannot be established, replace compressor.
Compressor Stage 2 will not activate	Faulty Stage 2 module	Verify if 24VAC is present across Y2 and C of the terminal strip.	Replace module if signal is present. Check wiring if signal is not present.

OPERATION TROUBLESHOOTING - HEATING MODE

Fault	Possible Cause	Verification	Recommended Action
High Discharge Pressure	Air Flow	See Fan Troubleshooting section	Correct the problem.
	TXV adjusted too far closed.	Verify superheat. It should be between 8-12°F (3-6°C). Superheat will be high if TXV is closed too far.	Adjust TXV to obtain 8-12°F (3-6°C) superheat.
	TXV stuck almost closed or partially blocked by foreign object.	Adjusting the TXV does not affect the superheat or the suction pressure.	Adjust the TXV all the way in and out a few times to loosen it. Replace TXV if this does not work.
	Filter-drier plugged	Feel each end of the filter- drier, it should be the same temperature. If there is a temperature difference then it is plugged. Also causes low suction pressure.	Replace filter-drier.
	Unit is overcharged. (Only possible if unit has been opened in the field and incorrectly charged).	High sub-cooling, low delta T across air coil.	Remove 1/2lb of refrigerant at a time and verify that the discharge pressure reduces.
Low Suction Pressure	Low or no Outdoor liquid flow	Delta T across the Outdoor Loop ports should be between 5-7°F (3-4°C), or compare pressure drop to the tables for the unit.	Determine the cause of the flow restriction and correct it. Verify pumps are working and sized correctly for ground loop systems. Verify well pump and water valve is working for ground water systems.
	Entering liquid temperature too cold.	Measure the entering liquid temperature. Most likely caused by undersized ground loop.	Increase the size of the ground loop.
	Dirty or fouled coaxial heat exchanger. (typically for ground water, unlikely for ground loop)	Disconnect the water lines and check the inside of the pipes for scale deposits.	Have a qualified service technician backflush the coaxial exchanger.
	Return air too cold	Measure return air temperature. Should be above 60°F (15°C).	Restrict air flow temporarily until room comes up to temperature.
	TXV stuck almost closed or partially blocked by foreign object.	Adjusting the TXV does not affect the superheat or the suction pressure. TXV may be frosting up.	Adjust the TXV all the way in and out a few times to loosen it. Replace TXV if this does not work.
	Low refrigerant charge.	Entering liquid temperature, flow and entering air temperature are good but suction is low. Check static refrigeration pressure of the unit for a very low value.	Locate the leak and repair it. Spray nine, a sniffer and dye are common methods of locating a leak.
	Faulty compressor, not pumping.	Pressures change only slightly from static values when compressor is started.	Replace compressor.

OPERATION TROUBLESHOOTING - HEATING MODE

Fault	Possible Cause	Verification	Recommended Action
High Suction Pressure (may appear to not be pumping)	Leaking reversing valve.	Reversing valve is the same temperature on both ends of body, common suction line is warm, compressor is running hot.	Replace reversing valve.
	TXV adjusted too far open.	Verify superheat. It should be between 8-12°F (3-6°C). Superheat will be low if TXV is open too far.	Adjust TXV to obtain 8-12°F (3-6°C) superheat.
	TXV stuck open.	Adjusting the TXV does not affect the superheat or the suction pressure. Low super heat and discharge pressure.	Adjust the TXV all the way in and out a few times to loosen it. Replace TXV if this does not work.
Compressor frosting up	See Low Suction Pressure in this section.		
TXV frosting up	TXV stuck almost closed or partially blocked by foreign object.	Adjusting the TXV does not affect the superheat or the suction pressure.	Attempt to adjust the TXV all the way out and all the way in a few times to loosen it. Replace TXV if this does not work.
Random high pressure trip (does not occur while on site)	Faulty compressor contactor.	Points pitted or burned. Contactor sometimes sticks causing the compressor to run without the fan, tripping the high pressure control.	Replace contactor.
	Intermittent fan.	See Fan Troubleshooting section.	Correct the problem.

OPERATION TROUBLESHOOTING - COOLING MODE

Fault	Possible Cause	Verification	Recommended Action
Heating instead of cooling	Thermostat not set up properly.	Verify that there is 24VAC across O/B/W1 and C of the terminal strip when calling for cooling.	Correct thermostat setup. Change to a different thermostat.
	Faulty reversing valve solenoid coil.	Verify solenoid by removing it from the shaft while the unit is running. There should be a loud "whoosh" sound when it is removed.	Replace solenoid if faulty.
	Faulty reversing valve.	A click can be heard when the coil is energized but the unit continues to heat instead of cool.	Replace reversing valve.
High Discharge pressure	Low or no Outdoor liquid flow	Delta T across the Outdoor Loop ports should be between 8-12°F (4-7°C), or compare pressure drop to the tables for the unit.	Determine the cause of the flow restriction and correct it. Verify pumps are working for ground loop systems. Verify well pump and water valve is working for ground water systems.
	Entering liquid temperature too warm.	Most likely caused by undersized ground loop.	Verify the ground loop sizing. Increase the size of the ground loop if undersized.
	Dirty or fouled coaxial heat exchanger. (typically for ground water, unlikely for ground loop)	Disconnect the water lines and check the inside of the pipes for scale deposits.	Have a qualified service technician backflush the coaxial exchanger.

OPERATION TROUBLESHOOTING - COOLING MODE

Fault	Possible Cause	Verification	Recommended Action
High Discharge pressure	Unit is overcharged. (Only possible if unit has been opened in the field and incorrectly charged).	High sub-cooling, low delta T across water coil.	Remove 1/2lb of refrigerant at a time and verify that the discharge pressure reduces.
High Suction Pressure (may appear to not be pumping)	TXV adjusted too far open.	Verify superheat. It should be between 8-12°F (3-6°C). Superheat will be low if TXV is open too far.	Adjust TXV to obtain 8-12°F (3-6°C) superheat.
	TXV stuck open.	Adjusting the TXV does not affect the superheat or the suction pressure. Low super heat and discharge pressure.	Adjust the TXV all the way in and out a few times to loosen it. Replace TXV if this does not work.
	Leaking reversing valve.	Reversing valve is the same temperature on both ends of body, common suction line is warm, compressor is running hot.	Replace reversing valve.
Low Suction Pressure	Air Flow	See Fan Troubleshooting section. Note: low airflow will cause the air coil to ice up once the suction drops below 90PSIG .	Correct the problem.
	TXV stuck almost closed or partially blocked by foreign object.	Adjusting the TXV does not affect the superheat or the suction pressure. TXV may be frosting up.	Adjust the TXV all the way in and out a few times to loosen it. Replace TXV if this does not work.
	Low or no refrigerant charge.	Entering air temperature and airflow are good but suction is low. Check static refrigeration pressure of unit for very low value.	Locate the leak and repair it. Spray nine, a sniffer and dye are common methods of locating a leak.
	Faulty compressor, not pumping.	Pressures change only slightly from static values when compressor is started.	Replace compressor.
Compressor frosting up	See Low Suction Pressure in this section.		
TXV frosting up	TXV stuck almost closed or partially blocked by foreign object.	Adjusting the TXV does not affect the superheat or the suction pressure.	Adjust the TXV all the way in and out a few times to loosen it. Replace TXV if this does not work.
Random Low Pressure trip (does not occur while there)	Faulty compressor contactor.	Points pitted or burned. Contactor sometimes sticks causing the compressor to run without the fan, tripping the low pressure control.	Replace contactor.
	Intermittent fan.	See Fan Troubleshooting section.	Correct the problem.

FAN TROUBLESHOOTING


Fault	Possible Cause	Verification	Recommended Action
Low Airflow	Dirty air filter	Inspect.	Replace.
	Dirty air coil.	Inspect.	Clean.
	Poor Ductwork	Measure delta T between supply and return ducts at the unit, it in heating mode, it should not be above 30°F(17°C).	The ECM fan will provide proper airflow up to 0.5 inH2o for 1/2HP motors and 0.7 inH2o for 1HP motors. The ductwork is poorly designed or greatly undersized if the fan motor cannot provide the required airflow.
	Air flow selected on Tap Board is too low.	Check selection on Air Flow Tap Board.	Select a higher setting.
	Air flow reduction is enabled.	AR1 and AR2 are connected with a dry contact.	Air flow reduction may not be feasible with poor ductwork, and/or lower Air Flow selections. Increase settings until unit operates properly.
Fan operating on wrong Stage speed	Fan Control Signal Harness is loose.	Verify that the connector is properly inserted into the fan motor. Gently tug on each wire to verify it is properly inserted into the connector.	Repair any loose connections.
	Faulty Control Signal Harness or faulty motor head. Ensure signal is present on terminal strip.	Measure 24VAC between White (pin 3) and the following at the fan control signal harness (insert probes in connector where wire is inserted, do not unplug the connector): Circulation = Grey (pin 15) Stage 1 = Yellow (pin 6) Stage 2=Yellow/Black (pin14) Stage 3 = Violet (pin 2)	If proper signal isn't present, replace Fan Control Signal Harness. If proper signal is present, replace fan motor head.
Fan not operating or operating intermittently	Fan Control Signal Harness and/or Fan Power Harness is loose.	Verify that the connector is properly inserted into the fan motor. Gently tug on each wire to verify it is properly inserted into the connector.	Repair any loose connections.
	Faulty Control Signal Harness or faulty motor head. Ensure signal is present on terminal strip.	Measure 24VAC between White (pin 3) and the following at the fan control signal harness (insert probes in connector where wire is inserted, do not unplug the connector): Circulation = Grey (pin 15) Stage 1 = Yellow (pin 6) Stage 2=Yellow/Black (pin14) Stage 3 = Violet (pin 2)	If proper signal isn't present, replace Fan Control Signal Harness. If proper signal is present, replace fan motor head.
	Faulty Fan Power Harness or faulty motor.	Insert the tips of the voltmeter probes into the back of the connector at the fan to measure the voltage across the red and black wires, value should be 230VAC	Replace Power Harness if 230VAC is not present, replace motor if 230VAC is present

PLENUM HEATER TROUBLE SHOOTING

Fault	Possible Cause	Verification	Recommended Action
No 230VAC across plenum heater L1 and L2	Disconnect switch open. (if installed)	Verify disconnect switch is in the ON position.	Determine why the disconnect switch was opened, if all is OK close the switch.
	Fuse blown / Breaker Tripped.	At plenum heater disconnect box (if installed), voltmeter shows voltage on the line side but not on the load side. Check if breaker is tripped.	Reset breaker or replace fuse at plenum heater disconnect box. Replace fuse with proper size and type. (Time-delay type "D")
	Same "Line" to L1 and L2	Measuring L1 to ground and L2 to ground both yield 115VAC, but L1 to L2 yields 0VAC.	Correct wiring.
No W2 signal at Heat pump terminal strip	No call for auxiliary or emergency heat from thermostat.	Verify that the thermostat is indicating that auxiliary or emergency heat should be on.	Set thermostat to engage auxiliary or emergency heat (note some thermostats require a jumper between auxiliary and emergency. Check the thermostat manual).
	Faulty thermostat.	Thermostat doesn't indicate a call for auxiliary or emergency when it should.	Replace thermostat.
	Faulty thermostat.	Thermostat indicates auxiliary or emergency but no 24VAC signal present across C and the auxiliary and/or emergency pin at the thermostat.	Replace thermostat.
	Faulty thermostat wiring.	24VAC signal is present across C and the auxiliary and/or emergency pin at the thermostat but no 24VAC signal is present across W2 and C at the heat pump terminal strip.	Correct wiring.
No 24VAC signal from C to ground at the plenum heater control connector	Plenum Heater transformer is burned out.	Voltmeter does not show 24VAC across transformer secondary winding.	Replace transformer.
	Plenum heater control board is faulty.	Transformer tested OK in previous step.	Replace control board.
No 24VAC signal from 1 to ground at the plenum heater control connector	Faulty wiring.	24VAC present across C and ground at the plenum heater, but not across ground of the plenum heater and 1 of the heat pump terminal strip	Correct wiring.
	Faulty wiring.	If previous step tested OK, 24VAC is present across ground of the plenum heater and 1 of the heat pump terminal strip, but not across ground of the plenum heater and 1 of the plenum heater.	Correct wiring.

PLENUM HEATER TROUBLE SHOOTING			
Fault	Possible Cause	Verification	Recommended Action
No 24VAC signal from 1 to ground at the plenum heater control connector	Faulty Plenum Heater Relay in heat pump	24VAC is present across pin 1 and pin 3 of the relay, 24VAC is present from heat pump terminal strip 1 to plenum heater ground, but not from heat pump terminal strip 1 to plenum heater ground.	Replace relay.
Thermal overload is tripped.	Fan not operating	See Fan Not Operating section	Correct problem. Reset thermal overload.
	Faulty overload	Reset thermal overload	Replace if faulty.

DOMESTIC HOT WATER (DHW) TROUBLE SHOOTING			
Fault	Possible Cause	Verification	Recommended Action
Insufficient hot water (Tank Problem)	Thermostat on hot water tank set too low. Should be set at 120°F. (140°F if required by local code)	Visually inspect the setting.	Readjust the setting to 120°F. (140°F if required by local code)
	Breaker tripped, or fuse blown in electrical supply to hot water tank.	Check both line and load sides of fuses. If switch is open determine why.	Replace blown fuse or reset breaker.
	Reset button tripped on hot water tank.	Check voltage at elements with multimeter.	Push reset button.
Insufficient hot water (Heat Pump Problem)	Circulator pump not operating.	Visually inspect the pump to see if shaft is turning. Use an amprobe to measure current draw.	Replace if faulty.
	Blockage or restriction in the water line or hot water heat exchanger.	Check water flow and power to pump. Check water lines for obstruction	Remove obstruction in water lines. Acid treat the domestic hot water coil.
	Faulty DHW cutout (failed open).	Check contact operation. Should close at 120°F and open at 140°F.	Replace DHW cutout if faulty.
	Heat pump not running enough hours to make sufficient hot water.	Note the amount of time the heat pump runs in any given hour.	Temporarily turn up the tank thermostats until colder weather creates longer run cycles.
Water is too hot.	Faulty DHW cutout (failed closed).	Check contact operation. Should close at 120°F and open at 140°F.	Replace DHW cutout if faulty.
	Thermostat on hot water tank set too high. Should be set at 120°F. (140°F if required by local code)	Visually inspect the setting.	Readjust the setting to 120°F. (140°F if required by local code)




Refrigeration Gauges




In-line Flowmeter


Trouble Shooting Tools



Digital Thermometer



Multimeter -
Voltmeter /
Amp probe



Dole flow control Valve

The Dole® flow control is a simple, self-cleaning device designed to deliver a constant volume of water from any outlet whether the pressure is 15 psig or as high as 125 psi. The controlling mechanism consists of a flexible orifice that varies its area inversely with pressure so that a constant flow is maintained.

REPAIR PROCEDURES

PUMP DOWN PROCEDURE

STEP 1	Connect the refrigerant recovery unit to the heat pump service ports via a refrigeration charging manifold and to a recovery tank as per the instructions in the recovery unit manual. If there was a compressor burn out, the refrigerant cannot be reused and must be disposed of according to local codes.
STEP 2	All water coil heat exchangers must either have full flow or be completely drained of fluid before recovery begins. Failure to do so can freeze and rupture the heat exchanger, voiding its warranty. (Note that this does not apply to double wall domestic hot water exchangers (desuperheater coils))
STEP 3	Ensure all hose connections are properly purged of air. Start the refrigerant recovery as per the instructions in the recovery unit manual.
STEP 4	Allow the recovery unit suction pressure to reach a vacuum. Once achieved, close the charging manifold valves. Shut down, purge and disconnect the recovery unit as per the instructions in its manual. Ensure the recovery tank valve is closed before disconnecting the hose to it.
STEP 5	Connect a nitrogen tank to the charging manifold and add nitrogen to the heat pump until a positive pressure of 5-10PSIG is reached. This prevents air from being sucked into the unit by the vacuum when the hoses are disconnected.
STEP 6	The heat pump is now ready for repairs. Always ensure nitrogen is flowing through the system during any soldering procedures to prevent soot buildup inside the pipes. Maritime Geothermal Ltd. recommends replacing the liquid line filter-drier anytime the refrigeration system has been exposed to the atmosphere.

VACUUM AND CHARGING PROCEDURE

STEP 1	After completion of repairs and nitrogen pressure testing, the refrigeration circuit is ready for vacuuming.
STEP 2	Release the refrigerant circuit pressure and connect the vacuum pump to the charging manifold. Start the vacuum pump and open the charging manifold valves. Vacuum until the vacuum gauge remains at less than 500 microns for at least 1 minute with the vacuum pump valve closed.
STEP 3	Close the charging manifold valves then shut off and disconnect the vacuum pump. Place a refrigerant tank with the proper refrigerant on a scale and connect it to the charging manifold. Purge the hose to the tank.
STEP 4	Weigh in the appropriate amount of refrigerant through the low pressure (suction) service port. Refer to the label on the unit or the Refrigerant Charge Chart in the MODEL SPECIFIC INFORMATION section for the proper charge amount.
STEP 5	If the unit will not accept the entire charge, the remainder can be added through the low pressure service port after the unit has been restarted.

REPLACEMENT PROCEDURE FOR A COMPRESSOR BURN-OUT

STEP 1	Pump down the unit as per the Pump Down Procedure above. Discard the refrigerant according to local codes.
STEP 2	Replace the compressor. Replace the liquid line filter-drier.
STEP 3	Vacuum the unit until it remains under 500 microns for several minutes with the vacuum pump valve closed.
STEP 4	Charge the unit with NEW REFRIGERANT and operate it for continuously for 2 hours. Pump down the unit and replace the filter-drier. Vacuum the unit until it remains under 500 microns for several minutes with the vacuum pump valve closed.
STEP 5	Charge the unit (refrigerant can be re-used) and operate it for 2-3 days. Perform an acid test. If it fails, pump down the unit and replace the filter-drier.
STEP 6	Charge the unit (refrigerant can be re-used) and operate it for 2 weeks. Perform an acid test, If it fails pump down the unit and replace the filter-drier.
STEP 7	Charge the unit a final time. Unit should now be clean and repeated future burn-outs can be avoided.

Model Specific Information

This section provides general information particular to each model. For complete specifications please see the specifications document for the desired model.

REFRIGERANT CHARGE CHART

Table 14 - Refrigerant - R410a		
SIZE	Lbs.	kg
25	7.5	3.4
45	7.5	3.4
55	8.0	3.6
65	10.0	4.5
75	12.5	5.7
80	11.5	5.2
System contains POE oil.		

SHIPPING INFORMATION

Table 15 - Shipping Information				
MODEL	WEIGHT	DIMENSIONS in (cm)		
	Lbs. (kg)	L	W	H
25	370 (168)	44 (112)	36 (91)	66 (167)
45	390 (177)	44 (112)	36 (91)	66 (167)
55	460 (209)	44 (112)	36 (91)	66 (167)
65	490 (222)	44 (112)	36 (91)	66 (167)
75	530 (240)	44 (112)	36 (91)	66 (167)
80	598 (271)	44 (112)	36 (91)	68 (173)

STANDARD CAPACITY RATINGS

The tables below depict the results of standard capacity rating tests according to C13256-1, which is identical to ISO13256-1. Stage 1 values do not apply to single stage units. Refer to the [Electrical Tables](#) to determine which models are single stage.

Table 16 - Standard Capacity Ratings - Ground Loop Heating*											60Hz		
EAT 68°F (20°C)						STAGE 1 - ELT 41°F (5°C) STAGE 2 - ELT 32°F (0°C)							
Model	Nominal Size	Liquid Flow		Pressure Drop		Mode	Airflow		Input Energy	Capacity		COP _H	
	Tons	USGPM	L/s	PSI	kPA		CFM	L/s	Watts	BTU/Hr	kW	W/W	
25	2	8.0	0.50	2.9	20.0	Stage 1	680	320	1,035	15,200	4.5	4.3	
						Stage 2	800	378	1,450	18,300	5.4	3.7	
45	3	10.0	0.63	4.4	30.8	Stage 1	1030	486	1,535	22,000	6.4	4.2	
						Stage 2	1200	566	2,155	27,200	8.0	3.7	
55	4	12.0	0.76	4.1	28.3	Stage 1	1240	585	2,045	29,300	8.6	4.2	
						Stage 2	1500	708	2,700	35,900	10.5	3.9	
65	5	14.0	0.88	5.3	36.5	Stage 1	1540	727	2,565	35,900	10.5	4.1	
						Stage 2	1900	897	3,390	44,000	12.8	3.8	
75	6	16.0	1.01	4.1	28.6	Stage 1	1660	783	3,435	45,700	13.4	3.9	
						Stage 2	2100	991	4,355	53,500	15.7	3.6	
80	6	17.0	1.07	4.5	31.0	Stage 1	2400	1133	4,940	63,000	18.4	3.7	
* 15% NaCl by Weight Ground Loop Fluid													REV-09A

* 15% NaCl by Weight Ground Loop Fluid

REV-09

Table 17 - Standard Capacity Ratings - Ground Water Heating											60Hz	
EAT 68°F (20°C)						ELT 50°F (10°C)						
Model	Nominal Size	Liquid Flow		Pressure Drop		Mode	Airflow		Input Energy	Capacity		COP _H
	Tons	USGPM	L/s	PSI	kPA		CFM	L/s	Watts	BTU/Hr	kW	W/W
25	2	8.0	0.50	2.7	18.6	Stage 1	680	320	1,070	17,900	5.2	4.9
						Stage 2	800	378	1,540	23,100	6.8	4.4
45	3	10.0	0.63	4.0	27.3	Stage 1	1030	486	1,625	25,500	7.5	4.6
						Stage 2	1200	566	2,375	35,700	10.5	4.4
55	4	12.0	0.76	3.5	24.1	Stage 1	1240	585	2,075	34,700	10.2	4.9
						Stage 2	1500	708	2,960	47,500	13.9	4.7
65	5	14.0	0.88	4.3	29.7	Stage 1	1540	727	2,670	42,800	12.5	4.7
						Stage 2	1900	897	3,740	58,700	17.2	4.6
75	6	16.0	1.01	3.6	24.8	Stage 1	1660	783	3,540	52,000	15.2	4.3
						Stage 2	2100	991	4,780	68,500	20.1	4.2
80	6	17.0	1.07	4.1	28.3	Stage 1	2400	1133	5,315	77,500	22.7	4.3

REV-04

REV-09

STANDARD CAPACITY RATINGS (continued)

Table 18 - Standard Capacity Ratings - Ground Loop Cooling*											60Hz		
EAT 80.6°F (27°C)											STAGE 1 - ELT 68°F (20°C) STAGE 2 - ELT 77°F (25°C)		
Model	Size	Liquid Flow		Pressure Drop		Mode	Airflow		Input Energy	Capacity		COP _c	EER
	Tons	USGPM	L/s	PSI	kPA		CFM	L/s	Watts	BTU/Hr	kW	W/W	BTU/W
25	2	8.0	0.50	2.7	18.5	Stage 1	680	320	790	20,100	5.9	7.5	25.5
						Stage 2	800	378	1,460	24,800	7.3	5.7	17.0
45	3	10.0	0.63	3.7	25.5	Stage 1	1030	486	1,130	26,800	7.8	6.9	23.7
						Stage 2	1200	566	2,155	35,100	10.3	4.8	16.3
55	4	12.0	0.76	3.8	26.2	Stage 1	1240	585	1,470	36,000	10.5	7.2	24.5
						Stage 2	1500	708	2,640	45,700	13.4	5.1	17.3
65	5	14.0	0.88	4.1	28.2	Stage 1	1540	727	1,910	45,500	13.3	6.7	23.8
						Stage 2	1900	897	3,445	57,600	16.9	4.9	16.8
75	6	16.0	1.01	3.5	24.2	Stage 1	1660	783	2,620	55,000	16.1	6.3	21.0
						Stage 2	2100	991	4,300	67,500	19.8	4.7	15.7
80	6	17.0	1.07	4.2	29.0	Stage 1	2400	1133	4,950	84,200	24.7	5.00	17.1

* 15% NaCl by Weight Ground Loop Fluid

REV-09

* 15% NaCl by Weight Ground Loop Fluid

REV-09

Table 19 - Standard Capacity Ratings - Ground Water Cooling											60Hz		
EAT 80.6°F (27°C)											ELT 59°F (15°C)		
Model	Size	Liquid Flow		Pressure Drop		Mode	Airflow		Input Energy	Capacity		COP _c	EER
	Tons	USGPM	L/s	PSI	kPA		CFM	L/s	Watts	BTU/Hr	kW	W/W	BTU/W
25	2	8.0	0.50	2.6	18.1	Stage 1	680	320	640	21,000	6.2	9.6	32.7
						Stage 2	800	378	1,160	26,800	7.9	6.8	23.1
45	3	10.0	0.63	3.7	28.3	Stage 1	1030	486	1,080	29,500	8.6	8.0	27.3
						Stage 2	1200	566	1,805	38,500	11.3	6.2	21.3
55	4	12.0	0.76	3.3	22.7	Stage 1	1240	585	1,315	37,500	11.0	8.3	28.5
						Stage 2	1500	708	2,245	50,500	14.8	6.6	22.5
65	5	14.0	0.88	4.1	28.0	Stage 1	1540	727	1,705	47,200	13.8	8.1	27.5
						Stage 2	1900	897	2,865	62,600	18.3	6.4	21.8
75	6	16.0	1.01	3.4	23.6	Stage 1	1660	783	2,305	56,500	16.6	7.2	24.5
						Stage 2	2100	991	3,710	72,000	21.1	5.7	19.4
80	6	17.0	1.07	3.9	26.9	Stage 1	2400	1133	4,130	87,900	25.8	6.23	21.1

REV-09

REV-09

CAPACITY RATINGS

Heating Mode

R-25-HACW-P-1T						Nominal 2 ton					R410a 60 Hz					
Source Data (Outdoor Loop)						Power Consumption					Sink Data (Indoor Loop)					
ELT	Evap. Temp	Flow	LLT	Delta T	HAB	Compressor		Fan*	Effective	COPh	EAT	Cond. Temp.	Air Flow	LAT	Delta T	Net Output
°F °C	°F °C	USGPM L/s	°F °C	°F °C	BTU/Hr Watts	Watts	Amps	Watts	Watts	W/W	°F °C	°F °C	CFM L/s	°F °C	°F °C	BTU/Hr Watts
24.0	15	7.0	20.4	3.6	12,091	1,431	6.6	73	1,497	3.33	68	100	800	89.3	21.3	17,019
-4.4	-9.4	0.442	-6.5	2.0	3,543						20.0	37.8	378	31.8	11.8	4,987
30.0	20	7.0	26.0	4.0	13,328	1,460	6.7	73	1,526	3.52	68	102	800	90.9	22.9	18,355
-1.1	-6.7	0.442	-3.3	2.2	3,905						20.0	38.9	378	32.7	12.7	5,378
36.0	25	7.0	31.6	4.4	14,644	1,491	6.9	73	1,556	3.72	68	104	800	92.7	24.7	19,776
2.2	-3.9	0.442	-0.2	2.4	4,291						20.0	40.0	378	33.7	13.7	5,794
42.0	30	7.0	37.1	4.9	16,286	1,531	7.0	73	1,597	3.96	68	106	800	94.9	26.9	21,555
5.6	-1.1	0.442	2.8	2.7	4,772						20.0	41.1	378	35.0	15.0	6,315
45.0	35	7.0	39.8	5.2	18,061	1,575	7.2	73	1,633	4.21	68	108	800	97.9	29.9	23,469
7.2	1.7	0.442	4.4	2.9	5,292						20.0	42.2	378	36.6	16.6	6,876
51.0	40	7.0	45.4	5.6	19,694	1,614	7.4	73	1,673	4.42	68	110	800	100.2	32.2	25,236
10.6	4.4	0.442	7.4	3.1	5,770						20.0	43.3	378	37.9	17.9	7,394
57.0	45	7.0	50.9	6.1	21,427	1,658	7.6	73	1,716	4.63	68	112	800	102.6	34.6	27,119
13.9	7.2	0.442	10.5	3.4	6,278						20.0	44.4	378	39.2	19.2	7,946
63.0	50	7.0	56.3	6.7	23,268	1,706	7.8	73	1,764	4.84	68	114	800	105.1	37.1	29,123
17.2	10.0	0.442	13.5	3.7	6,817						20.0	45.6	378	40.6	20.6	8,533

Compressor: ZPS20K5E-PFV

* @ 37.3Pa (0.15inH2o) Ext. Static

Cooling Mode

R-25-HACW-P-1T												R410a 60 Hz							
Source Data (Indoor Loop)								Power Consumption					Sink Data (Outdoor Loop)						
EAT	Evap. Temp	Airflow	LAT	Delta T	Latent	Sensible	HAB	Compressor		Fan*	Effective	Efficiency	ELT	Cond. Temp.	Flow	LLT	Delta T	Rejection	
°F °C	°F °C	CFM L/s	°F °C	°F °C	BTU/Hr Watts	BTU/Hr Watts	BTU/Hr Watts	Watts	Amps	Watts	Watts	EER COPc	°F °C	°F °C	USGPM L/s	°F °C	°F °C	BTU/Hr Watts	
80.6	46	800	56.3	24.3	9,561	20,629	30,190	1,142	4.5	68	1,203	25.1	53	70	7.0	62.8	9.8	34,321	
27.0	7.8	378	13.5	13.5	2,801	6,044	8,846					7.35	11.7	21.1	0.442	17.1	5.5	10,056	
80.6	47	800	56.6	24.0	9,422	20,328	29,749	1,206	4.8	68	1,266	23.5	58	75	7.0	67.7	9.7	34,097	
27.0	8.1	378	13.7	13.3	2,760	5,956	8,716					6.88	14.4	23.9	0.442	19.9	5.4	9,990	
80.6	47	800	57.0	23.6	9,270	20,001	29,271	1,276	5.1	68	1,337	21.9	63	80	7.0	72.7	9.7	33,859	
27.0	8.3	378	13.9	13.1	2,716	5,860	8,576					6.42	17.2	26.7	0.442	22.6	5.4	9,920	
80.6	47	800	58.4	22.2	8,716	18,805	27,521	1,320	5.4	68	1,380	19.9	68	85	7.0	77.2	9.2	32,257	
27.0	8.5	378	14.7	12.3	2,554	5,510	8,064					5.84	20.0	29.4	0.442	25.1	5.1	9,451	
80.6	48	800	59.0	21.6	7,841	17,951	25,792	1,366	5.7	68	1,425	18.1	73	90	7.0	82.2	9.2	30,687	
27.0	8.7	378	15.0	12.0	2,297	5,260	7,557					5.30	22.8	32.2	0.442	27.9	5.1	8,991	
80.6	48	800	59.5	21.1	7,679	17,580	25,258	1,453	6.1	68	1,512	16.7	78	95	7.0	87.2	9.2	30,450	
27.0	8.9	378	15.3	11.7	2,250	5,151	7,401					4.89	25.6	35.0	0.442	30.6	5.1	8,922	
80.6	49	800	59.9	20.7	7,507	17,187	24,694	1,547	6.5	68	1,606	15.4	83	100	7.0	92.1	9.1	30,206	
27.0	9.2	378	15.5	11.5	2,200	5,036	7,235					4.51	28.3	37.8	0.442	33.4	5.0	8,850	
80.6	49	800	60.4	20.2	7,326	16,774	24,100	1,648	6.9	68	1,707	14.1	88	105	7.0	97.0	9.0	29,958	
27.0	9.4	378	15.8	11.2	2,147	4,915	7,061					4.14	31.1	40.6	0.442	36.1	5.0	8,778	

Compressor: ZPS20K5E-PFV

* @ 37.3Pa (0.15inH2o) Ext. Static

CAPACITY RATINGS (continued)

Heating Mode

R-45-HACW-P-1T						Nominal 3 ton					R410a 60 Hz						
Source Data (Outdoor Loop)						Power Consumption					Sink Data (Indoor Loop)						
ELT	Evap. Temp	Flow	LLT	Delta T	HAB	Compressor	Fan*	Effective	COPh	EAT	Cond. Temp.	Air Flow	LAT	Delta T	Net Output		
°F	°F	USGPM	°F	°F	BTU/Hr	Watts	Amps	Watts	W/W	°F	°F	CFM	°F	°F	BTU/Hr	Watts	
°C	°C	L/s	°C	°C	Watts					°C	°C	L/s	°C	°C	Watts		
26.0	15	10.0	21.9	4.1	19,393	1,963	8.4	179	2,128	3.63	61	96	1,200	83.7	22.7	26,396	
-3.3	-9.4	0.631	-5.6	2.3	5,682						16.1	35.6	566	28.7	12.6	7,734	
32.0	20	10.0	27.6	4.4	21,005	2,045	8.8	179	2,211	3.75	62	99	1,200	86.3	24.3	28,290	
0.0	-6.7	0.631	-2.5	2.5	6,154						16.7	37.2	566	30.2	13.5	8,289	
38.0	25	10.0	33.2	4.8	22,718	2,130	9.1	179	2,295	3.87	63	102	1,200	89.0	26.0	30,291	
3.3	-3.9	0.631	0.7	2.7	6,656						17.2	38.9	566	31.7	14.5	8,875	
44.0	30	10.0	38.7	5.3	25,249	2,239	9.5	179	2,404	4.05	63	105	1,200	91.5	28.5	33,196	
6.7	-1.1	0.631	3.7	3.0	7,398						17.2	40.6	566	33.1	15.8	9,726	
49.0	35	10.0	43.4	5.6	28,175	2,324	9.8	179	2,479	4.30	63	107	1,200	94.3	31.3	36,401	
9.4	1.7	0.631	6.3	3.1	8,255						17.2	41.7	566	34.6	17.4	10,665	
55.0	40	10.0	48.9	6.1	30,329	2,417	10.2	179	2,572	4.43	63	110	1,200	96.4	33.4	38,873	
12.8	4.4	0.631	9.4	3.4	8,886						17.2	43.3	566	35.8	18.6	11,390	
61.0	45	10.0	54.5	6.5	32,592	2,514	10.6	179	2,669	4.55	64	113	1,200	99.6	35.6	41,467	
16.1	7.2	0.631	12.5	3.6	9,549						17.8	45.0	566	37.6	19.8	12,150	
67.0	50	10.0	60.0	7.0	34,965	2,615	11.1	179	2,770	4.67	65	116	1,200	103.0	38.0	44,185	
19.4	10.0	0.631	15.6	3.9	10,245						18.3	46.7	566	39.4	21.1	12,946	

Compressor: ZPS30K5E-PFV

* @ 37.3Pa (0.15inH2o) Ext. Static

Cooling Mode

R-45-HACW-P-1T								R410a 60 Hz										
Source Data (Indoor Loop)								Power Consumption				Sink Data (Outdoor Loop)						
EAT	Evap. Temp	Airflow	LAT	Delta T	Latent	Sensible	HAB	Compressor	Fan*	Effective	Efficiency	ELT	Cond. Temp.	Flow	LLT	Delta T	Rejection	
°F	°F	CFM	°F	°F	BTU/Hr	BTU/Hr	BTU/Hr	Watts	Amps	Watts	Watts	EER	°F	°F	USGPM	°F	BTU/Hr	
°C	°C	L/s	°C	°C	Watts	Watts	Watts					COPc	°C	°C	L/s	°C	Watts	
80.6	44	1,200	57.4	23.2	13,299	28,417	41,716	1,487	6.0	171	1,642	25.4	51	70	10.0	60.5	9.5	47,375
27.0	6.6	566	14.1	12.9	3,897	8,326	12,223					7.44	10.6	21.1	0.631	15.8	5.3	13,881
80.6	44	1,200	57.7	22.9	13,115	28,024	41,140	1,611	6.4	171	1,766	23.3	56	75	10.0	65.5	9.5	47,222
27.0	6.8	566	14.3	12.7	3,843	8,211	12,054					6.82	13.3	23.9	0.631	18.6	5.3	13,836
80.6	45	1,200	58.0	22.6	12,968	27,709	40,677	1,737	6.9	171	1,892	21.5	61	80	10.0	70.4	9.4	47,190
27.0	7.2	566	14.4	12.6	3,800	8,119	11,918					6.30	16.1	26.7	0.631	21.4	5.2	13,826
80.6	46	1,200	58.4	22.2	12,721	27,182	39,904	1,881	7.4	171	2,036	19.6	66	85	10.0	75.4	9.4	46,908
27.0	7.6	566	14.7	12.3	3,727	7,964	11,692					5.74	18.9	29.4	0.631	24.1	5.2	13,744
80.6	46	1,200	58.7	21.9	12,344	26,670	39,014	2,031	7.9	171	2,192	17.8	72	90	10.0	81.8	9.8	46,530
27.0	7.9	566	14.8	12.2	3,617	7,814	11,431					5.22	22.2	32.2	0.631	27.7	5.4	13,633
80.6	47	1,200	59.0	21.6	12,165	26,283	38,447	2,171	8.4	171	2,332	16.5	77	95	10.0	86.8	9.8	46,441
27.0	8.3	566	15.0	12.0	3,564	7,701	11,265					4.83	25.0	35.0	0.631	30.4	5.4	13,607
80.6	48	1,200	59.4	21.2	11,931	25,777	37,707	2,317	9.0	171	2,478	15.2	82	100	10.0	91.7	9.7	46,200
27.0	8.6	566	15.2	11.8	3,496	7,552	11,048					4.46	27.8	37.8	0.631	33.2	5.4	13,537
80.6	48	1,200	59.9	20.7	11,685	25,246	36,931	2,471	9.6	171	2,632	14.0	87	105	10.0	96.7	9.7	45,950
27.0	8.9	566	15.5	11.5	3,424	7,397	10,821					4.11	30.6	40.6	0.631	35.9	5.4	13,463
Compressor: ZPS30K5E-PFV													* @ 37.3Pa (0.15inH2o) Ext. Static					

Compressor: ZPS30K5E-PFV

* @ 37.3Pa (0.15inH2o) Ext. Static

CAPACITY RATINGS (continued)

Heating Mode

R-55-HACW-P-1T						Nominal 4 ton					R410a 60 Hz					
Source Data (Outdoor Loop)						Power Consumption					Sink Data (Indoor Loop)					
ELT	Evap. Temp	Flow	LLT	Delta T	HAB	Compressor		Fan*	Effective	COPh	EAT	Cond. Temp.	Air Flow	LAT	Delta T	Net Output
°F	°F	USGPM	°F	°F	BTU/Hr	Watts	Amps	Watts	Watts	W/W	°F	°F	CFM	°F	°F	BTU/Hr
°C	°C	L/s	°C	°C	Watts						°C	°C	L/s	°C	°C	Watts
27.0	15	12.0	22.3	4.7	26,809	2,567	11.8	185	2,718	3.86	68	98	1,500	91.6	23.6	35,782
-2.8	-9.4	0.757	-5.4	2.6	7,855						20.0	36.7	708	33.1	13.1	10,484
33.0	20	12.0	27.8	5.2	29,763	2,633	12.1	185	2,784	4.10	68	100	1,500	93.7	25.7	38,963
0.6	-6.7	0.757	-2.3	2.9	8,721						20.0	37.8	708	34.3	14.3	11,416
39.0	25	12.0	33.2	5.8	32,940	2,699	12.5	185	2,850	4.36	68	102	1,500	96.0	28.0	42,364
3.9	-3.9	0.757	0.7	3.2	9,651						20.0	38.9	708	35.5	15.5	12,413
45.0	30	12.0	38.7	6.3	36,095	2,791	12.8	185	2,942	4.56	68	104	1,500	98.3	30.3	45,834
7.2	-1.1	0.757	3.7	3.5	10,576						20.0	40.0	708	36.8	16.8	13,429
50.0	35	12.0	43.4	6.6	39,435	2,885	13.1	185	3,033	4.78	68	106	1,500	100.0	32.0	49,511
10.0	1.7	0.757	6.3	3.7	11,554						20.0	41.1	708	37.8	17.8	14,507
56.0	40	12.0	48.8	7.2	43,264	2,955	13.4	185	3,102	5.06	68	108	1,500	102.7	34.7	53,577
13.3	4.4	0.757	9.3	4.0	12,676						20.0	42.2	708	39.3	19.3	15,698
62.0	45	12.0	54.1	7.9	47,338	3,026	13.8	185	3,174	5.34	68	110	1,500	105.5	37.5	57,895
16.7	7.2	0.757	12.3	4.4	13,870						20.0	43.3	708	40.8	20.8	16,963
68.0	50	12.0	59.4	8.6	51,663	3,100	14.1	185	3,247	5.64	68	112	1,500	108.4	40.4	62,471
20.0	10.0	0.757	15.2	4.8	15,137						20.0	44.4	708	42.5	22.5	18,304
Compressor: ZPS40K5E-PFV																
* @ 37.3Pa (0.15inH2o) Ext. Static																

Compressor: ZPS40K5E-PFV

* @ 37.3Pa (0.15inH2o) Ext. Static

Cooling Mode

R-55-HACW-P-1T													R410a 60 Hz					
Source Data (Indoor Loop)								Power Consumption				Sink Data (Outdoor Loop)						
EAT	Evap. Temp	Airflow	LAT	Delta T	Latent	Sensible	HAB	Compressor		Fan*	Effective	Efficiency	ELT	Cond. Temp.	Flow	LLT	Delta T	Rejection
°F	°F	CFM	°F	°F	BTU/Hr	BTU/Hr	BTU/Hr	Watts	Amps	Watts	Watts	EER	°F	°F	USGPM	°F	°F	BTU/Hr
°C	°C	L/s	°C	°C	Watts	Watts	Watts					COPc	°C	°C	L/s	°C	°C	Watts
80.6	43.6	1,500	58.3	22.3	16,911	36,135	53,046	1,993	8.5	192	2,151	24.7	51	70	12.0	61.1	10.1	60,504
27.0	6.4	708	14.6	12.4	4,955	10,587	15,542					7.23	10.6	21.1	0.757	16.2	5.6	17,727
80.6	43.8	1,500	58.7	21.9	16,606	35,484	52,090	2,139	9.1	192	2,297	22.7	56	75	12.0	66.0	10.0	60,047
27.0	6.6	708	14.8	12.2	4,866	10,397	15,262					6.64	13.3	23.9	0.757	18.9	5.6	17,593
80.6	44	1,500	59.1	21.5	16,289	34,806	51,095	2,287	9.7	192	2,444	20.9	61	80	12.0	70.9	9.9	59,555
27.0	6.7	708	15.1	11.9	4,773	10,198	14,971					6.12	16.1	26.7	0.757	21.6	5.5	17,449
80.6	44.3	1,500	59.5	21.1	15,993	34,173	50,166	2,373	10.3	192	2,530	19.8	66	85	12.0	75.8	9.8	58,920
27.0	6.8	708	15.3	11.7	4,686	10,013	14,699					5.81	18.9	29.4	0.757	24.3	5.5	17,263
80.6	45	1,500	60.2	20.4	16,727	32,470	49,197	2,455	11.0	192	2,614	18.8	71	90	12.0	81.2	10.2	58,230
27.0	7.0	708	15.7	11.3	4,901	9,514	14,415					5.51	21.7	32.2	0.757	27.3	5.7	17,061
80.6	45	1,500	60.6	20.0	16,409	31,853	48,262	2,605	11.6	192	2,764	17.5	76	95	12.0	86.1	10.1	57,809
27.0	7.2	708	15.9	11.1	4,808	9,333	14,141					5.12	24.4	35.0	0.757	30.1	5.6	16,938
80.6	45	1,500	61.1	19.5	16,009	31,077	47,087	2,761	12.3	192	2,920	16.1	81	100	12.0	91.0	10.0	57,166
27.0	7.3	708	16.1	10.9	4,691	9,106	13,796					4.72	27.2	37.8	0.757	32.8	5.6	16,749
80.6	45	1,500	61.6	19.0	15,594	30,270	45,864	2,924	13.0	192	3,083	14.9	86	105	12.0	95.9	9.9	56,499
27.0	7.4	708	16.4	10.6	4,569	8,869	13,438					4.36	30.0	40.6	0.757	35.5	5.5	16,554

Compressor: ZPS40K5E-PFV

* @ 37.3Pa (0.15inH2o) Ext. Static

CAPACITY RATINGS (continued)

Heating Mode

R-65-HACW-P-1T						Nominal 5 ton					R410a 60 Hz					
Source Data (Outdoor Loop)						Power Consumption					Sink Data (Indoor Loop)					
ELT	Evap. Temp	Flow	LLT	Delta T	HAB	Compressor		Fan*	Effective	COPh	EAT	Cond. Temp.	Flow	LAT	Delta T	Net Output
°F	°F	USGPM	°F	°F	BTU/Hr	Watts	Amps	Watts	Watts	W/W	°F	°F	CFM	°F	°F	BTU/Hr
°C	°C	L/s	°C	°C	Watts						°C	°C	L/min	°C	°C	Watts
26.0	15	14.0	21.2	4.8	31,644	3,290	14.9	300	3,573	3.56	68	97	1,900	90.6	22.6	43,391
-3.3	-9.4	0.883	-6.0	2.6	9,272						20.0	36.1	897	32.6	12.6	12,713
32.0	20	14.0	26.8	5.2	34,798	3,384	15.3	300	3,667	3.74	68	99	1,900	92.4	24.4	46,866
0.0	-6.7	0.883	-2.9	2.9	10,196						20.0	37.2	897	33.6	13.6	13,732
38.0	25	14.0	32.3	5.7	37,954	3,522	15.9	300	3,806	3.89	68	102	1,900	94.3	26.3	50,495
3.3	-3.9	0.883	0.2	3.2	11,120						20.0	38.9	897	34.6	14.6	14,795
44.0	30	14.0	37.6	6.4	42,566	3,620	16.3	300	3,903	4.16	68	104	1,900	96.9	28.9	55,440
6.7	-1.1	0.883	3.1	3.6	12,472						20.0	40.0	897	36.1	16.1	16,244
49.0	35	14.0	42.2	6.8	47,314	3,765	16.9	300	4,045	4.40	68	107	1,900	99.0	31.0	60,717
9.4	1.7	0.883	5.7	3.8	13,863						20.0	41.7	897	37.2	17.2	17,790
55.0	40	14.0	47.6	7.4	51,599	3,865	17.4	300	4,144	4.62	68	109	1,900	101.4	33.4	65,344
12.8	4.4	0.883	8.7	4.1	15,118						20.0	42.8	897	38.5	18.5	19,146
61.0	45	14.0	53.0	8.0	56,159	3,968	17.8	300	4,247	4.85	68	111	1,900	103.9	35.9	70,253
16.1	7.2	0.883	11.7	4.5	16,455						20.0	43.9	897	39.9	19.9	20,584
67.0	50	14.0	58.3	8.7	61,001	4,074	18.3	300	4,353	5.08	68	113	1,900	106.6	38.6	75,456
19.4	10.0	0.883	14.6	4.8	17,873						20.0	45.0	897	41.4	21.4	22,108
Compressor: ZPS51K5E-PFV																
* @ 49.7Pa (0.20inH2o) Ext. Static																

Compressor: ZPS51K5E-PFV

* @ 49.7Pa (0.20inH2o) Ext. Static

Cooling Mode

R-65-HACW-P-1T												R410a 60 Hz						
Source Data (Indoor Loop)								Power Consumption				Sink Data (Outdoor Loop)						
EAT	Evap. Temp	Airflow	LAT	Delta T	Latent	Sensible	HAB	Compressor	Fan*	Effective	Efficiency	ELT	Cond. Temp.	Flow	LLT	Delta T	Rejection	
°F	°F	CFM	°F	°F	BTU/Hr	BTU/Hr	BTU/Hr	Watts	Amps	Watts	Watts	EER	°F	°F	USGPM	°F	°F	
°C	°C	L/s	°C	°C	Watts	Watts	Watts					COPc	°C	°C	L/s	°C	°C	
80.6	44.8	1,900	56.0	24.6	19,665	49,095	68,760	2,373	10.8	325	2,663	25.8	49	70	14.0	60.1	11.1	
27.0	7.1	897	13.3	13.7	5,762	14,385	20,147					7.56	9.4	21.1	0.883	15.6	6.2	
80.6	45.1	1,900	56.4	24.2	19,362	48,337	67,698	2,574	11.6	325	2,864	23.6	54	75	14.0	65.1	11.1	
27.0	7.3	897	13.5	13.5	5,673	14,163	19,835					6.93	12.2	23.9	0.883	18.4	6.2	
80.6	45.4	1,900	56.8	23.8	19,043	47,542	66,585	2,777	12.4	325	3,067	21.7	59	80	14.0	70.0	11.0	
27.0	7.4	897	13.8	13.2	5,580	13,930	19,509					6.36	15.0	26.7	0.883	21.1	6.1	
80.6	45.7	1,900	57.5	23.1	18,462	46,091	64,553	2,896	13.2	325	3,186	20.3	64	85	14.0	74.8	10.8	
27.0	7.6	897	14.2	12.8	5,409	13,504	18,914					5.94	17.8	29.4	0.883	23.8	6.0	
80.6	46	1,900	58.0	22.6	18,682	43,799	62,481	3,008	14.0	325	3,307	18.9	70	90	14.0	81.1	11.1	
27.0	7.8	897	14.4	12.6	5,474	12,833	18,307					5.54	21.1	32.2	0.883	27.3	6.2	
80.6	46	1,900	58.5	22.1	18,309	42,926	61,235	3,214	14.8	325	3,513	17.4	75	95	14.0	86.0	11.0	
27.0	7.9	897	14.7	12.3	5,365	12,577	17,942					5.11	23.9	35.0	0.883	30.0	6.1	
80.6	47	1,900	58.9	21.7	17,919	42,012	59,931	3,429	15.7	325	3,728	16.1	80	100	14.0	90.9	10.9	
27.0	8.1	897	15.0	12.0	5,250	12,309	17,560					4.71	26.7	37.8	0.883	32.7	6.1	
80.6	47	1,900	59.4	21.2	17,512	41,056	58,567	3,653	16.6	325	3,952	14.8	85	105	14.0	95.8	10.8	
27.0	8.3	897	15.2	11.8	5,131	12,029	17,160					4.34	29.4	40.6	0.883	35.5	6.0	

Compressor: ZPS51K5E-PFV

* @ 49.7Pa (0.20inH2o) Ext. Static

CAPACITY RATINGS (continued)

Heating Mode

R-75-HACW-P-1T						Nominal 6 ton					R410a 60 Hz					
Source Data (Outdoor Loop)						Power Consumption					Sink Data (Indoor Loop)					
ELT	Evap. Temp	Flow	LLT	Delta T	HAB	Compressor		Fan*	Effective	COPh	EAT	Cond. Temp.	Air Flow	LAT	Delta T	Net Output
°F	°F	USGPM	°F	°F	BTU/Hr	Watts	Amps	Watts	Watts	W/W	°F	°F	CFM	°F	°F	BTU/Hr
°C	°C	L/s	°C	°C	Watts						°C	°C	L/s	°C	°C	Watts
28.0	15	16.0	22.9	5.1	38,593	3,695	17.5	410	4,094	3.73	68	97	2,100	92.6	24.6	52,075
-2.2	-9.4	1.009	-5.0	2.8	11,308						20.0	36.1	991	33.6	13.6	15,258
34.0	20	16.0	28.4	5.6	42,497	3,787	17.9	410	4,186	3.94	68	99	2,100	94.5	26.5	56,292
1.1	-6.7	1.009	-2.0	3.1	12,452						20.0	37.2	991	34.7	14.7	16,493
40.0	25	16.0	33.9	6.1	46,404	3,922	18.5	410	4,320	4.11	68	102	2,100	96.6	28.6	60,659
4.4	-3.9	1.009	1.1	3.4	13,596						20.0	38.9	991	35.9	15.9	17,773
46.0	30	16.0	39.3	6.7	50,856	4,068	19.0	410	4,466	4.30	68	104	2,100	98.9	30.9	65,609
7.8	-1.1	1.009	4.1	3.7	14,901						20.0	40.0	991	37.2	17.2	19,223
51.0	35	16.0	44.1	6.9	55,258	4,264	19.7	410	4,643	4.46	68	107	2,100	100.7	32.7	70,689
10.6	1.7	1.009	6.7	3.8	16,191						20.0	41.7	991	38.2	18.2	20,712
57.0	40	16.0	49.5	7.5	60,316	4,364	20.1	410	4,743	4.70	68	109	2,100	103.2	35.2	76,088
13.9	4.4	1.009	9.7	4.2	17,672						20.0	42.8	991	39.5	19.5	22,294
63.0	45	16.0	54.8	8.2	65,697	4,467	20.6	410	4,845	4.95	68	111	2,100	105.8	37.8	81,818
17.2	7.2	1.009	12.7	4.6	19,249						20.0	43.9	991	41.0	21.0	23,973
69.0	50	16.0	60.1	8.9	71,411	4,572	21.1	410	4,951	5.20	68	113	2,100	108.6	40.6	87,893
20.6	10.0	1.009	15.6	5.0	20,923						20.0	45.0	991	42.6	22.6	25,752

Compressor: ZPS60K5E-PFV

* @ 49.7Pa (0.20inH2o) Ext. Static

Cooling Mode

R-75-HACW-P-1T													R410a 60 Hz					
Source Data (Indoor Loop)								Power Consumption				Sink Data (Outdoor Loop)						
EAT	Evap. Temp	Airflow	LAT	Delta T	Latent	Sensible	HAB	Compressor		Fan*	Effective	Efficiency	ELT	Cond. Temp.	Flow	LLT	Delta T	Rejection
°F	°F	CFM	°F	°F	BTU/Hr	BTU/Hr	BTU/Hr	Watts	Amps	Watts	Watts	EER	°F	°F	USGPM	°F	°F	BTU/Hr
°C	°C	L/s	°C	°C	Watts	Watts	Watts					COPc	°C	°C	L/s	°C	°C	Watts
80.6	44	2,100	59.4	21.2	24,039	51,083	75,123	2,991	13.1	450	3,412	22.0	52	70	16.0	62.9	10.9	86,865
27.0	6.7	991	15.2	11.8	7,043	14,967	22,011					6.45	11.1	21.1	1.009	17.1	6.0	25,451
80.6	44.1	2,100	59.9	20.7	23,576	50,099	73,675	3,197	13.9	450	3,619	20.4	57	75	16.0	67.8	10.8	86,123
27.0	6.7	991	15.5	11.5	6,908	14,679	21,586					5.96	13.9	23.9	1.009	19.9	6.0	25,234
80.6	44.2	2,100	60.3	20.3	23,097	49,082	72,179	3,407	14.7	450	3,828	18.9	62	80	16.0	72.7	10.7	85,342
27.0	6.8	991	15.7	11.3	6,767	14,381	21,148					5.52	16.7	26.7	1.009	22.6	5.9	25,005
80.6	44.3	2,100	60.6	20.0	22,755	48,353	71,108	3,519	15.6	450	3,941	18.0	67	85	16.0	77.6	10.6	84,654
27.0	6.8	991	15.9	11.1	6,667	14,167	20,834					5.29	19.4	29.4	1.009	25.3	5.9	24,803
80.6	44	2,100	60.3	20.3	21,843	48,167	70,010	3,625	16.5	450	4,050	17.3	73	90	16.0	84.0	11.0	83,917
27.0	6.9	991	15.7	11.3	6,400	14,113	20,513					5.06	22.8	32.2	1.009	28.9	6.1	24,587
80.6	45	2,100	60.8	19.8	21,321	47,017	68,338	3,838	17.4	450	4,263	16.0	78	95	16.0	88.9	10.9	82,973
27.0	6.9	991	16.0	11.0	6,247	13,776	20,023					4.70	25.6	35.0	1.009	31.6	6.1	24,311
80.6	45	2,100	61.3	19.3	20,782	45,828	66,610	4,060	18.3	450	4,485	14.9	83	100	16.0	93.8	10.8	82,003
27.0	7.0	991	16.3	10.7	6,089	13,427	19,517					4.35	28.3	37.8	1.009	34.3	6.0	24,027
80.6	45	2,100	61.8	18.8	20,225	44,599	64,824	4,292	19.3	450	4,717	13.7	88	105	16.0	98.7	10.7	81,008
27.0	7.1	991	16.6	10.4	5,926	13,067	18,993					4.03	31.1	40.6	1.009	37.0	5.9	23,735

Compressor: ZPS60K5E-PFV

* @ 49.7Pa (0.20inH2o) Ext. Static

CAPACITY RATINGS (continued)

Heating Mode

R-80-HACW-P-1S											Nominal 6 ton						R410a 60 Hz	
Source Data (Outdoor Loop)						Power Consumption					Sink Data (Indoor Loop)							
ELT	Evap. Temp	Flow	LLT	Delta T	HAB	Compressor		Fan*	Effective	COPh	EAT	Cond. Temp.	Air Flow	LAT	Delta T	Net Output		
°F	°F	USGPM	°F	°F	BTU/Hr	Watts	Amps	Watts	Watts	W/W	°F	°F	CFM	°F	°F	BTU/Hr		
°C	°C	L/s	°C	°C	Watts						°C	°C	L/s	°C	°C	Watts		
25.0	15	16.8	19.9	5.1	40,320	4,366	23.5	661	4,869	3.41	68	98	2,400	92.8	24.8	56,598		
-3.9	-9.4	1.060	-6.7	2.8	11,814						20.0	36.7	1,133	33.8	13.8	16,583		
31.0	20	16.8	25.3	5.7	45,235	4,449	23.8	661	4,951	3.66	68	100	2,400	95.1	27.1	61,795		
-0.6	-6.7	1.060	-3.7	3.1	13,254						20.0	37.8	1,133	35.1	15.1	18,106		
37.0	25	16.8	30.7	6.3	50,440	4,531	24.2	661	5,033	3.92	68	102	2,400	97.5	29.5	67,279		
2.8	-3.9	1.060	-0.7	3.5	14,779						20.0	38.9	1,133	36.4	16.4	19,713		
43.0	30	16.8	36.2	6.8	53,978	4,649	24.5	661	5,151	4.05	68	104	2,400	99.2	31.2	71,219		
6.1	-1.1	1.060	2.4	3.8	15,815						20.0	40.0	1,133	37.4	17.4	20,867		
48.0	35	16.8	41.2	6.8	57,024	4,830	25.1	661	5,365	4.10	68	107	2,400	100.9	32.9	75,029		
8.9	1.7	1.060	5.1	3.8	16,708						20.0	41.7	1,133	38.3	18.3	21,983		
54.0	40	16.8	46.5	7.5	62,791	4,908	25.5	661	5,444	4.36	68	109	2,400	103.6	35.6	81,064		
12.2	4.4	1.060	8.1	4.2	18,397						20.0	42.8	1,133	39.8	19.8	23,752		
60.0	45	16.8	51.8	8.2	68,924	4,985	25.8	661	5,520	4.64	68	111	2,400	106.4	38.4	87,458		
15.6	7.2	1.060	11.0	4.6	20,195						20.0	43.9	1,133	41.3	21.3	25,625		
66.0	50	16.8	57.0	9.0	75,450	5,058	26.1	661	5,594	4.94	68	113	2,400	109.3	41.3	94,236		
18.9	10.0	1.060	13.9	5.0	22,107						20.0	45.0	1,133	43.0	23.0	27,611		

Compressor: ZP70KWE-PFV

* @ 49.7Pa (0.20inH2o) Ext. Static

Cooling Mode

R-80-HACW-P-1S											R410a 60 Hz							
Source Data (Indoor Loop)							Power Consumption					Sink Data (Outdoor Loop)						
EAT	Evap. Temp	Airflow	LAT	Delta T	Latent	Sensible	HAB	Compressor		Fan*	Effective	Efficiency	ELT	Cond. Temp.	Flow	LLT	Delta T	Rejection
°F	°F	CFM	°F	°F	BTU/Hr	BTU/Hr	BTU/Hr	Watts	Amps	Watts	Watts	EER	°F	°F	USGPM	°F	°F	BTU/Hr
°C	°C	L/s	°C	°C	Watts	Watts	Watts					COPc	°C	°C	L/s	°C	°C	Watts
80.6	44.5	2,400	56.4	24.2	29,318	60,890	90,208	3,081	17.6	710	3,611	25.0	47	75	16.8	59.3	12.3	103,148
27.0	6.9	1,133	13.6	13.4	8,590	17,841	26,431					7.32	8.3	23.9	1.060	15.2	6.8	30,222
80.6	45.1	2,400	56.6	24.0	29,075	60,387	89,462	3,293	18.5	710	3,823	23.4	52	80	16.8	64.3	12.3	103,125
27.0	7.3	1,133	13.7	13.3	8,519	17,693	26,212					6.86	11.1	26.7	1.060	17.9	6.8	30,215
80.6	45.8	2,400	56.8	23.8	28,842	59,903	88,744	3,512	19.5	710	4,041	22.0	57	85	16.8	69.3	12.3	103,154
27.0	7.7	1,133	13.8	13.2	8,451	17,551	26,002					6.43	13.9	29.4	1.060	20.7	6.8	30,224
80.6	46.5	2,400	57.2	23.4	28,443	59,074	87,517	3,790	20.5	710	4,319	20.3	62	90	16.8	74.3	12.3	102,874
27.0	8.1	1,133	14.0	13.0	8,334	17,308	25,642					5.94	16.7	32.2	1.060	23.5	6.8	30,142
80.6	47	2,400	57.2	23.4	27,062	58,850	85,912	4,088	21.6	710	4,642	18.5	71	95	16.8	83.8	12.8	102,288
27.0	8.4	1,133	14.0	13.0	7,929	17,243	25,172					5.42	21.7	35.0	1.060	28.8	7.1	29,970
80.6	48	2,400	57.6	23.0	26,694	58,048	84,742	4,353	22.7	710	4,908	17.3	76	100	16.8	88.8	12.8	102,023
27.0	8.8	1,133	14.2	12.8	7,821	17,008	24,829					5.06	24.4	37.8	1.060	31.5	7.1	29,892
80.6	48	2,400	58.0	22.6	26,222	57,022	83,243	4,640	23.9	710	5,194	16.0	81	105	16.8	93.7	12.7	101,503
27.0	9.1	1,133	14.4	12.6	7,683	16,707	24,390					4.70	27.2	40.6	1.060	34.3	7.1	29,740
80.6	49	2,400	58.4	22.2	25,700	55,887	81,587	4,950	25.3	710	5,504	14.8	86	110	16.8	98.6	12.6	100,905
27.0	9.4	1,133	14.7	12.3	7,530	16,375	23,905					4.34	30.0	43.3	1.060	37.0	7.0	29,565

Compressor: ZP70KWE-PFV

* @ 49.7Pa (0.20inH2o) Ext. Static

ELECTRICAL TABLES

Table 20 - Heat Pump Electrical Information (208/230-1-60)

Model	Compressor		Fan	Outdoor Circulators	FLA	MCA	Max Fuse/ Breaker	Wire Size**
	RLA	LRA	RLA	Max A	Amps	Amps	Amps	ga
25	11.4	52	2.5	4.0	18.7	21.6	30	#10-2
45	18.6	82	3.5	4.0	26.9	31.6	40	#8-2
55	23.6	96	4.0	5.0	33.4	39.3	50	#8-2
65	28.6	118	5.5	5.0	39.9	47.1	60	#6-2
75	30.4	150	6.5	5.0	42.7	50.3	60	#6-2
80*	35.7	148	7.0	5.0	48.5	57.4	60	#6-2

* Models are single stage

** Three (3) wire required if connecting 115VAC circulators to the unit.

Table 21 - Heat Pump Electrical Information (208-3-60)

Model	Compressor		Fan	Outdoor Circulators	FLA	MCA	Max Fuse/ Breaker	Wire Size**
	RLA	LRA	RLA	Max A	Amps	Amps	Amps	ga
25	7.9	59	2.5	4.0	15.2	17.2	25	#10-3
45	12.4	58	3.5	4.0	20.7	23.8	30	#10-3
55	15.0	88	4.0	5.0	24.8	28.6	40	#8-3
65	19.6	123	5.5	5.0	30.9	35.8	50	#8-3
75	21.2	123	6.5	5.0	33.5	38.8	60	#6-3
80*	25.0	149	7.0	5.0	37.8	44.1	60	#6-3

* Models are single stage

** Four (4) wire required if connecting 115VAC circulators to the unit.

Table 22 - Heat Pump Electrical Information (460-3-60)

Model	Compressor		Fan	Outdoor Circulators	FLA	MCA	Max Fuse/ Breaker	Wire Size
	RLA	LRA	RLA	Max A	Amps	Amps	Amps	ga
25	3.9	28	2.5	-	7.2	8.2	15	#12-3
45	6.4	38	3.5	-	10.7	12.3	20	#12-3
55	7.1	41	4.0	-	11.9	13.7	20	#12-3
65	8.1	52	5.5	-	14.4	16.4	25	#10-3
75	9.4	66	6.5	-	16.7	19.1	30	#10-3
80*	11.8	75	7.0	-	19.6	22.6	30	#10-3

* Models are single stage

Table 23 - Heat Pump Electrical Information (220-1-50)

Model	Compressor		Fan	Outdoor Circulators	FLA	MCA	Max Fuse/ Breaker	Wire Size
	RLA	LRA	RLA	Max A	Amps	Amps	Amps	ga
25	10.3	52	2.5	4.0	17.6	20.2	30	#10-2
45*	15.0	67	3.5	4.0	23.3	27.1	40	#8-2
55*	17.7	98	4.0	5.0	27.5	31.9	50	#6-2
65*	27.3	153	5.5	5.0	38.6	45.4	60	#6-2
75*	32.9	176	6.5	5.0	45.2	53.4	80	#4-2

* Models are single stage

ELECTRICAL TABLES continued

Table 24 - Heat Pump Electrical Information (380-3-50)								
Model	Compressor		Fan	Outdoor Circulators	FLA	MCA	Max Fuse/ Breaker	Wire Size
	RLA	LRA	RLA	Max A	Amps	Amps	Amps	ga
25	3.9	27	2.5	4.0	11.2	12.2	15	#14-4
45	5.0	29	3.5	4.0	13.3	14.6	20	#12-4
55	7.1	41	4.0	5.0	16.9	18.7	25	#10-4
65	10.0	62	5.5	5.0	21.3	23.8	30	#10-4
75	10.9	64	6.5	5.0	23.2	25.9	40	#8-4
80*	11.8	74	7.0	5.0	24.6	27.6	40	#8-4

* Models are single stage


TABLE 25 - Plenum Heater Electrical Information															
	(230-1-60)					(208-1-60)					(220-1-50)				
Nominal (kW)	Actual (kW)	FLA (A)	MCA (A)	Breaker (A)	Wire Size	Actual (kW)	FLA (A)	MCA (A)	Breaker (A)	Wire Size	Actual (kW)	FLA (A)	MCA (A)	Breaker (A)	Wire Size
5	5	20.8	26.0	30	#10	3.8	18.1	22.6	30	#10	4.2	19.1	19.1	30	#10
7	7	29.2	36.5	40	#8	5.3	25.3	31.6	40	#8	5.9	26.7	26.7	40	#6
10	10	41.7	52.1	60	#6	7.5	36.1	45.1	50	#6	8.4	38.1	38.1	50	#6
15	15	62.5	78.1	80	#4	11.3	54.2	67.7	80	#4	12.6	57.2	57.2	80	#3
20	20	83.3	104.2	100	#3	15.0	72.2	90.3	100	#3	16.8	76.3	76.3	100	#3

ELECTRICAL DIAGRAMS—Size 25 to 75 (208/230-1-60)

R-Series Schematic Diagram 208/230-1-60 / Single/Two Stage Scroll ECM Fan / Slim Design

NOTE: Neutral (N) only required if connecting 115VAC circulators. The heat pump itself does not require a neutral.


NOTE: Connect the brown wire with the insulated terminal to the bottom left terminal of the compressor contactor (L1) marked "A" once lines are filled and purged. The DHW ON/OFF SWITCH can be used to enable/disable the pump.



					Drawn By Chris Geddes	Date 01 MAY 2013	<div>MARITIME GEOTHERMAL LTD.</div> <div>170 Plantation Rd. Pettitcodiac, NB E4Z 6H4</div>			
					Checked By Chris Geddes	Date 01 MAY 2013				
					Approved By Chris Geddes (ENG)	Date 01 MAY 2013				
					Approved By (MFG)	Date				
01	000212 (IR)	C. GEDDES	C. GEDDES	01 MAY 2013	Approved By	Date	Drawing Name R-25-75-HAC*-P-1*-**DE** Schematic Diagram			
REV	ECO #	IMPL BY	APVD BY	DATE	Approved By	Date	Size A	Drawing Number 001754SCH	Drawing Rev 01	SHEET 1 of 1

R-Series Electrical Box Diagram

208/230-1-60 / Single/Two Stage Scroll / ECM Fan / Slim Design



IMPORTANT NOTE FOR 208-1-60 POWER

Ensure red wire is connected to the 208 terminal on the transformer instead of the 230V terminal.

Domestic Hot Water Circulator Pump Instructions

If heat pump is to be operated without the hot water circulator connected to the water tank and flooded with water, remove the brown wire with the insulated terminal located here. **This pump is water lubricated and must not be run dry.** Once connected the external ON/OFF switch may be used to temporarily turn the pump off.

Outdoor Circulator Pumps (Ground Loop)

REFER TO LABEL IN UNIT FOR MAX AMPS

Connect 115VAC circulators to 115V
Connect 230VAC circulators to 230V
Connect "Gnd" to Gnd. Lug

208/230/115VAC CONNECTIONS

Wire	Colour	Contact
Line 2	Red	L2
Neutral*	White	N*
Line 1	Black	L1

Connect "Gnd" to Gnd. Lug

NOTE: Neutral (N) only required if connecting 115VAC circulators. The heat pump itself does not require a neutral.

Heat Pump Electrical Service Requirements

208/230VAC Single Phase 60Hz (208/230-1-60)

Model Size	Min. Circuit Ampacity	Min. Wire Gauge	TD Fuse or Breaker
25	22	10-3	30
45	33	8-3	40
55	39	8-3	50
65	47	6-3	60
75	50	6-3	60

Low Voltage Wiring (24VAC)

Thermostat Wiring

Use an 18-8 (7 for 1 stage) conductor cable. Connect the eight Thermostat Connections in the electrical box to the corresponding letters on the thermostat.

- C - 24VAC Common
- G - Fan
- Y1 - Stage1 Heat/Cool (Compressor On/Off)
- RH - 24VAC Hot
- L - Trouble Indicator
- W2 - Stage3 (2 for 1 stage) Heat (Plenum Heater)
- O - Cooling (Reversing Valve)
- Y2 - Stage2 (N/A for 1 stage) Heat/Cool (S2 Solenoid)

Airflow Reduction Wiring


Use an 18-2 conductor cable to connect Electrical Box [AR1 AR2] to dry contacts. Fan speed will be reduced by 15% for zone applications.

Plenum Heater Wiring

Use an 18-2 conductor cable to connect Electrical Box [I 1] to Plenum Heater [C 1] (or [I 1])

MARITIME GEOTHERMAL LTD.		170 Plantation Rd. Petitcodiac, NB E4Z 6H4	
Drawing Name			
R-25-75-HAC*-P-1*-*DE** Electrical Box Diagram			
Size	Drawing Number	Drawing Rev	SHEET
A	001755ELB	01	1 of 1

ELECTRICAL DIAGRAMS—Size 80 (208/230-1-60)



PLENUM HEATER OPERATION


- I & 1 provides a set of dry contacts for operating plenum heater.
- Fan will run automatically with Thermostat W2 signal.

AIRFLOW REDUCTION
Connect AR1 & AR2 together with dry contacts to reduce the airflow for zone applications.

					Drawn By Chris Geddes	Date 29 SEP 09	<div>MARITIME GEOTHERMAL LTD.</div> <div>170 Plantation Rd. Pettitcodiac, NB E4Z 6H4</div>					
					Checked By Chris Geddes	Date 29 SEP 09						
03	000203	C. GEDDES	C. GEDDES	26 SEP 12	Approved By Chris Geddes (ENG)	Date 29 SEP 09	Drawing Name R--HAC*-P-1*-*DE** Schematic Diagram					
02	000178	C. GEDDES	C. GEDDES	01 FEB 11	Approved By (MFG)	Date						
01	Initial Release	C. GEDDES	C. GEDDES	29 SEP 09	Approved By	Date	Size A		Drawing Number 001135SCH		REV 03	SHEET 1 of 1

R-Series Electrical Box Diagram

208/230-1-60 / Single/Two Stage Scroll / ECM Fan / Modular Design



Field
T'stat
Wiring
24VAC

Field
Wiring
208/
230VAC

Domestic Hot Water Circulator Pump Instructions:

If heat pump is to be operated without the hot water circulator connected to the water tank and flooded with water, remove the brown wire with the insulated terminal located here. This pump is water lubricated and must not be run dry. Once connected the external ON/OFF switch may be used to temporarily turn the pump off.

IMPORTANT NOTE FOR 208-1-60 POWER

Ensure red wire is connected to the 208 terminal on the transformer instead of the 230V terminal.

Low Voltage Wiring (24VAC)

Thermostat Wiring

Use an 18-8 (7 for 1 stage) conductor cable. Connect the eight Thermostat Connections in the electrical box to the corresponding letters on the thermostat.
C - 24VAC Common
G - Fan
Y1 - Stage1 Heat/Cool (Compressor On/Off)
RH - 24VAC Hot
L - Trouble Indicator
W2 - Stage3 (2 for 1 stage) Heat (Plenum Heater)
O - Cooling (Reversing Valve)
Y2 - Stage2 (N/A for 1 stage) Heat/Cool (S2 Solenoid)

Airflow Reduction Wiring

Use an 18-2 conductor cable to connect Electrical Box AR1 AR2 to dry contacts. Fan speed will be reduced by 15% for zone applications.

Plenum Heater Wiring

Use an 18-2 conductor cable to connect Electrical Box I 1 to Plenum Heater C 1 (or I 1)

Outdoor Circulator Pumps (Ground Loop)

REFER TO LABEL IN UNIT FOR MAX AMPS

Connect 115VAC circulators to 115V
Connect 230VAC circulators to 230V
Connect "Gnd" to Gnd. Lug

208/230/115VAC CONNECTIONS

Wire	Colour	Contactor
Line 2	Red	L2
Neutral*	White	N*
Line 1	Black	L1

Connect "Gnd" to Gnd. Lug

NOTE: Neutral (N) only required if connecting 115VAC circulators. The heat pump itself does not require a neutral.

Heat Pump Electrical Service Requirements 208/230VAC Single Phase 60Hz (208/230-1-60)


Model Size	Min. Circuit Ampacity	Min. Wire Gauge	TD Fuse or Breaker
25	22	10-3	30
45	33	8-3	40
55	39	8-3	50
65	47	6-3	60
75	50	6-3	60
80	57	6-3	60

02	000178	C. GEDDES	C. GEDDES	01 FEB 11	Drawn By Chris Geddes	Date 29 SEP 09	MARTIME GEOTHERMAL LTD. 170 Plantation Rd, Petitcodiac, NB E4Z 6H4
01	Initial Release	C. GEDDES	C. GEDDES	29 SEP 09	Checked By Chris Geddes	Date 29 SEP 09	
REV	ECO #	IMPL BY	APVD BY	DATE	Approved By Chris Geddes (ENG)	Date 29 SEP 09	
					Approved By (MFG)	Date	

Drawing Name R**-HAC*-P-1**-DE** Electrical Box Diagram			
Size A	Drawing Number 001136ELB	REV 02	SHEET 1 of 1


REFRIGERATION CIRCUIT DIAGRAMS

R(H)-Series Refrigeration Circuit - Heating Mode




					Drawn By Chris Geddes	Date 25 JAN 10	<div>MARITIME GEOTHERMAL LTD.</div> <div>170 Plantation Rd. Petitcodiac, NB E4Z 6H4</div>							
					Checked By Chris Geddes	Date 25 JAN 10								
03	000212	D. RHEULT	C. GEDDES	01 JAN 2014	Approved By Chris Geddes (ENG)	Date 25 JAN 10	Drawing Name R(H)-Series Refrigeration Circuit Diagram - Heating Mode							
02	000203	D. RHEULT	D. RHEULT	26 SEP 12	Approved By (MFG)	Date								
01	Initial Release	C. GEDDES	C. GEDDES	25 JAN 10	Approved By	Date	Size A		Drawing Number 001207RCD		Drawing Rev 03		SHEET 1 of 1	

R(H)-Series Refrigeration Circuit - Cooling Mode




					Drawn By Chris Geddes	Date 25 JAN 10	MARITIME GEOTHERMAL LTD. 170 Plantation Rd. Petitcodiac, NB E4Z 6H4
03	000212	C. GEDDES	C. GEDDES	01 JAN 2014	Checked By Chris Geddes	Date 25 JAN 10	
02	000203	D. RHEAULT	D. RHEAULT	26 SEP 12	Approved By Chris Geddes	Date 25 JAN 10	Drawing Name R(H)-Series Refrigeration Circuit Diagram - Cooling Mode
01	Initial Release	C. GEDDES	C. GEDDES	25 JAN 10	Approved By (MFG)	Date	
REV	ECO #	IMPL BY	APVD BY	DATE	Approved By	Date	Size A
							Drawing Number 001208RCD
							Drawing Rev 03
							SHEET 1 of 1


CASE DETAILS (LEFT RETURN)—Size 25 to 75




Front View—Left Return



Right Side View—Left Return (Size 25 & 45)




Left Side View—Left Return




Right Side View—Left Return (Size 55 to 75)

CASE DETAILS (LEFT RETURN)—Size 25 to 75 - continued




Top View (Size 25 & 45)




Top View (Size 55 to 75)


CASE DETAILS (RIGHT RETURN)—Size 25 to 75




Front View—Right Return



Left Side View—Right Return (Size 25 & 45)




Right Side View—Right Return




Left Side View—Right Return (Size 55 to 75)

CASE DETAILS (RIGHT RETURN)—Size 25 to 75 - continued




Top View (Size 25 & 45)




Top View (Size 55 to 75)


CASE DETAILS (LEFT RETURN)—Size 80




Front View—Left Return



Top View—Left Return




Left Side View—Left Return




Right Side View—Left Return


CASE DETAILS (RIGHT RETURN)—Size 80




Front View—Right Return



Top View—Right Return



Right Side View—Right Return




Left Side View—Right Return

APPENDIX A - Control Board Specifications

Lockout Protection Module

- Anti-short cycle/lockout control
- Pressure/flow switch monitoring
- Alarm output during lockout
- 5-minute anti-short cycle delay (5-second test mode)
- LED fault codes for lockout status
- Test mode for reduced test time
- Conformally coated for moisture protection



Mode of Operation

The control will begin the 5-minute time delay upon a Y call from the thermostat. After the time delay expires, the compressor contactor will be energized as long as the high and low pressure switches are closed. If either switch is open after the delay expires, the compressor will not energize. If either switch opens while the compressor is energized, it will de-energize immediately and begin the anti-short cycle delay. The compressor will not be allowed to turn on again until the anti-short cycle delay expires and both pressure switches are closed. The flow switch will have a 30-second bypass timer in which the control will ignore an open flow switch for the first 30 seconds. If the flow switch remains open after the 30-second bypass timer expires, the unit will de-energize the compressor and begin the anti-short cycle delay. If the control experiences three high pressure, low pressure, or flow switch faults in a 60-minute period, it will lockout the compressor and energize the fault output. A manual reset of power will be required to reset the lockout condition.

The control has a status LED to indicate which type of fault or lockout has occurred. If a high pressure fault or lockout occurs, the status LED will blink once. If a low pressure fault or lockout occurs, the status LED will blink twice. If a flow switch fault occurs, the status LED will blink three times.

Specifications

Input

- Voltage: 18 to 30 VAC
- Frequency: 50 to 60 Hz

Output

- CC
 - Type: Solid state (Triac)
 - Rating: 1 amp @ 30 VAC
- Fault
 - Type: Relay (SPDT) N.O.
 - Rating: 1 amp @ 30 VAC


Time Delay

- Anti-short cycle time: 5-minutes fixed $\pm 20\%$ (5-second test mode)

Mechanical

- Board dimensions: 3.5" x 3.25" x 1"
- Mounting: Surface mount using (4) #6 or #8 screws

Dimensions



APPENDIX B - ECM Fan Airflow Tables

NOMINAL AIRFLOW SETTING (MED)												
	STAGE 2				STAGE 1				FAN ONLY (Recirculation)			
Model	Full		Reduced*		Full		Reduced*		Full		Reduced*	
	CFM	L/s	CFM	L/s	CFM	L/s	CFM	L/s	CFM	L/s	CFM	L/s
25	800	378	680	321	680	321	578	273	448	211	381	180
45	1200	566	1020	481	1030	486	876	413	672	317	571	270
55	1500	708	1275	602	1240	585	1054	497	840	396	714	337
65	1900	897	1615	762	1540	727	1309	618	1064	502	904	427
75	2100	991	1785	842	1660	783	1411	666	1176	555	1000	472
80	2400	1133	2040	963	N/A	N/A	N/A	N/A	1344	634	1142	539

-6% AIRFLOW SETTING (LOW)												
	STAGE 2				STAGE 1				FAN ONLY (Recirculation)			
Model	Full		Reduced*		Full		Reduced*		Full		Reduced*	
	CFM	L/s	CFM	L/s	CFM	L/s	CFM	L/s	CFM	L/s	CFM	L/s
25	752	355	639	302	639	302	543	256	421	199	358	169
45	1128	532	959	453	968	457	823	388	632	298	537	253
55	1410	665	1199	566	1166	550	991	468	790	373	671	317
65	1786	843	1518	716	1448	683	1230	581	1000	472	850	401
75	1974	932	1678	792	1560	736	1326	626	1105	522	940	443
80	2256	1065	1918	905	N/A	N/A	N/A	N/A	1263	596	1074	507

+6% AIRFLOW SETTING (HIGH)												
	STAGE 2				STAGE 1				FAN ONLY (Recirculation)			
Model	Full		Reduced*		Full		Reduced*		Full		Reduced*	
	CFM	L/s	CFM	L/s	CFM	L/s	CFM	L/s	CFM	L/s	CFM	L/s
25	848	400	721	340	721	340	613	289	475	224	404	191
45	1272	600	1081	510	1092	515	928	438	712	336	605	286
55	1590	750	1352	638	1314	620	1117	527	890	420	757	357
65	2014	951	1712	808	1632	770	1388	655	1128	532	959	452
75	2226	1051	1892	893	1760	830	1496	706	1400	661	1190	562
80	2544	1201	2162	1021	N/A	N/A	N/A	N/A	1425	672	1211	572

+12% AIRFLOW SETTING (MAX)												
	STAGE 2				STAGE 1				FAN ONLY (Recirculation)			
Model	Full		Reduced*		Full		Reduced*		Full		Reduced*	
	CFM	L/s	CFM	L/s	CFM	L/s	CFM	L/s	CFM	L/s	CFM	L/s
25	896	423	762	359	762	359	647	306	502	237	426	201
45	1344	634	1142	539	1154	544	981	463	753	355	640	302
55	1680	793	1428	674	1389	655	1180	557	941	444	800	377
65	2128	1004	1809	854	1725	814	1466	692	1192	562	1013	478
75	2352	1110	1999	944	1859	877	1580	746	1317	622	1120	528
80	2688	1269	2285	1078	N/A	N/A	N/A	N/A	1505	710	1279	604

NOTES: Unit sizes 45 and 55 nominal value up to 0.50 inH₂O, sizes 65, 75 and 80 up to 0.70inH₂O

*To obtain the REDUCED airflow values use a dry contact to connect AR1 to AR2 on the terminal strip

THIS PAGE INTENTIONALLY LEFT BLANK

LIMITED EXPRESS WARRANTY

It is expressly understood that unless a statement is specifically identified as a warranty, statements made by Maritime Geothermal Ltd., a corporation registered in New Brunswick, Canada, ("MG") or its representatives, relating to MG's products, whether oral, written or contained in any sales literature, catalogue or agreement, are not express warranties and do not form a part of the basis of the bargain, but are merely MG's opinion or commendation of MG's products.

EXCEPT AS SPECIFICALLY SET FORTH HEREIN, THERE IS NO EXPRESS WARRANTY AS TO ANY OF MG'S PRODUCTS. MG MAKES NO WARRANTY AGAINST LATENT DEFECTS. MG MAKES NO WARRANTY OF MERCHANTABILITY OF THE GOODS OR OF THE FITNESS OF THE GOODS FOR ANY PARTICULAR PURPOSE.

LIMITED EXPRESS RESIDENTIAL WARRANTY - PARTS

MG warrants its Residential Class products, purchased and retained in the United States of America and Canada, to be free from defects in material and workmanship under normal use and maintenance as follows:

- (1) Air conditioning, heating and/or heat pump units built or sold by MG ("MG Units") for five (5) years from the Warranty Inception Date (as defined below).
- (2) Thermostats, auxiliary electric heaters and geothermal pumping modules built or sold by MG, when installed with MG Units, for five (5) years from the Warranty Inception Date (as defined below).
- (3) Sealed refrigerant circuit components of MG Units (which components only include the compressor, refrigerant to air/water heat exchangers, reversing valve body and refrigerant metering device) for ten (10) years from the Warranty Inception Date (as defined below).
- (4) Other accessories and parts built or sold by MG, when installed and purchased with MG Units, for five (5) years from the date of shipment from MG.
- (5) Other accessories, when purchased separately, for (1) year from the date of shipment from MG.

The "Warranty Inception Date" shall be the date of original unit installation, as per the date on the installation Startup Record or six (6) months from date of unit shipment from MG, whichever comes first.

To make a claim under this warranty, parts must be returned to MG in Petitcodiac, New Brunswick, freight prepaid, no later than ninety (90) days after the date of the failure of the part. If MG determines the part to be defective and within MG's Limited Express Residential Warranty, MG shall, when such part has been either replaced or repaired, return such to a factory recognized distributor, dealer or service organization, freight prepaid. The warranty on any part repaired or replaced under warranty expires at the end of the original warranty period.

LIMITED EXPRESS RESIDENTIAL WARRANTY - LABOUR

This Limited Express Residential Labour Warranty shall cover the **labour** incurred by MG authorized service personnel in connection with the installation of a new or repaired warranty part that is covered by this Limited Express Residential Warranty only to the extent specifically set forth in the current **labour** allowance schedule "A" provided by MG's Warranty Department and only as follows:

- (1) MG Units for two (2) years from the Warranty Inception Date.
- (2) Thermostats, auxiliary electric heaters and geothermal pump modules built or sold by MG, when installed with MG Units, for two (2) years from the Warranty Inception Date.
- (3) Sealed refrigerant circuit components of MG Units (which components only include the compressor, refrigerant to air/water heat exchangers, reversing valve body and refrigerant metering device) for five (5) years from the Warranty Inception Date.

Labour costs are not covered by this Limited Express Residential Warranty to the extent they **exceed** the amount allowed under said allowance schedule, they are not specifically provided for in said allowance schedule, they are not the result of work performed by MG authorized service personnel, they are incurred in connection with a part not covered by this Limited Express Residential Warranty, or they are incurred more than the time periods set forth in this paragraph after the Warranty Inception Date.

This warranty does not cover and does not apply to:

- (1) Air filters, fuses, refrigerant, fluids, oil.
- (2) Products relocated after initial installation.
- (3) Any portion or component of any system that is not supplied by MG, regardless of the cause of the failure of such portion or component.
- (4) Products on which the unit identification tags or labels have been removed or defaced.
- (5) Products on which payment to MG, or to the owner's seller or installing contractor, is in default.
- (6) Products subjected to improper or inadequate installation, maintenance, repair, wiring or voltage conditions.
- (7) Products subjected to accident, misuse, negligence, abuse, fire, flood, lightning, unauthorized alteration, misapplication, contaminated or corrosive liquid or air supply, operation at abnormal air or liquid temperatures or flow rates, or opening of the refrigerant circuit by unqualified personnel.
- (8) Mold, fungus or bacteria damage
- (9) Corrosion or abrasion of the product.
- (10) Products supplied by others.
- (11) Products which have been operated in a manner contrary to MG's printed instructions.
- (12) Products which have insufficient performance as a result of improper system design or improper application, installation, or use of MG's products.
- (13) Electricity or fuel, or any increases or unrealized savings in same, for any reason whatsoever.

Except for the limited **labour** allowance coverage set forth above, MG is not responsible for:

- (1) The costs of fluids, refrigerant or system components **supplied by others**, or associated **labour** to repair or replace the same, which is incurred as a result of a defective part covered by MG's Limited Residential Warranty.
- (2) The costs of **labour**, refrigerant, materials or service incurred in diagnosis and removal of the defective part, or in obtaining and replacing the new or repaired part.
- (3) Transportation costs of the defective part from the installation site to MG, or of the return of that part if not covered by MG's Limited Express Residential Warranty.
- (4) The costs of normal maintenance.

This Limited Express Residential Warranty applies to MG Residential Class products manufactured on or after February 15, 2010. MG'S LIABILITY UNDER THE TERMS OF THIS LIMITED WARRANTY SHALL APPLY ONLY TO THE MG UNITS REGISTERED WITH MG THAT BEARS THE MODEL AND SERIAL NUMBERS STATED ON THE INSTALLATION START UP RECORD, AND MG SHALL NOT, IN ANY EVENT, BE LIABLE UNDER THE TERMS OF THIS LIMITED WARRANTY UNLESS THIS INSTALLATION START UP RECORD HAS BEEN ENDORSED BY OWNER & DEALER/INSTALLER AND RECEIVED BY MG LIMITED WITHIN 90 DAYS OF START UP.

Limitation: This Limited Express Residential Warranty is given in lieu of all other warranties. If, notwithstanding the disclaimers contained herein, it is determined that other warranties exist, any such express warranty, including without limitation any express warranties or any implied warranties of fitness for particular purpose and merchantability, shall be limited to the duration of the Limited Express Residential Warranty.

LIMITATION OF REMEDIES In the event of a breach of the Limited Express Residential Warranty, MG will only be obligated at MG's option to repair the failed part or unit, or to furnish a new or rebuilt part or unit in exchange for the part or unit which has failed. If after written notice to MG's factory in Petitcodiac, New Brunswick of each defect, malfunction or other failure, and a reasonable number of attempts by MG to correct the defect, malfunction or other failure, and the remedy fails of its essential purpose, MG shall refund the purchase price paid to MG in exchange for the return of the sold good(s). Said refund shall be the maximum liability of MG. **THIS REMEDY IS THE SOLE AND EXCLUSIVE REMEDY OF THE BUYER OR PURCHASER AGAINST MG FOR BREACH OF CONTRACT, FOR THE BREACH OF ANY WARRANTY OR FOR MG'S NEGLIGENCE OR IN STRICT LIABILITY.**

LIMITATION OF LIABILITY MG shall have no liability for any damages if MG's performance is delayed for any reason or is prevented to any extent by any event such as, but not limited to: any war, civil unrest, government restrictions or restraints, strikes, or work stoppages, fire, flood, accident, shortages of transportation, fuel, material, or labour, acts of God or any other reason beyond the sole control of MG. **MG EXPRESSLY DISCLAIMS AND EXCLUDES ANY LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, SO THE FOREGOING EXCLUSIONS AND LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE AND FROM CANADIAN PROVINCE TO CANADIAN PROVINCE. PLEASE REFER TO THE MG INSTALLATION, INSTALLATION AND SERVICE MANUAL FOR OPERATING AND MAINTENANCE INSTRUCTIONS.**

OBTAINING WARRANTY PERFORMANCE Normally, the dealer or service organization who installed the products will provide warranty performance for the owner. Should the installer be unavailable, contact any MG recognized distributor, dealer or service organization. If assistance is required in obtaining warranty performance, write or call: Maritime Geothermal Ltd. • Customer Service • PO Box 2555 • Petitcodiac, New Brunswick E4Z 6H4 • (506) 756-8135 • or e-mail to info@nordicghp.com NOTE: Some states or Canadian provinces do not allow limitations on how long an implied warranty lasts, or the limitation or exclusions of consequential or incidental damages, so the foregoing exclusions and limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state and from Canadian province to Canadian province. Please refer to the MG Installation, Installation and Service Manual for operating and maintenance instructions.

An extended warranty option is also available. Please contact Maritime Geothermal Ltd. via the contact information in the previous paragraph for more information.